



IN APPLIED SCIENCE & ENGINEERING TECHNOLOGY

Volume: 10 Issue: X Month of publication: October 2022 DOI: https://doi.org/10.22214/ijraset.2022.47064

www.ijraset.com

Call: 🕥 08813907089 🔰 E-mail ID: ijraset@gmail.com

# Voltage Feed-Forward Controlled 75W Forward Converter with Type-2 Compensation and Protection Circuits

Kalpana N<sup>1</sup>, Shubha Kulkarni<sup>2</sup>, B K Singh<sup>3</sup> <sup>1, 2, 3</sup>Dept of Electrical & Electronics, Dayananda Sagar University

Abstract: In recent years, DC-DC converters find many applications in low to medium power range. The isolated converters are used in medium power application such as military, electric vehicle (EV) and space industries since they provide isolation between input and output and protection from input side faults. These are made capable of providing a specified output voltage by managing the PWM pulses delivered to the switching device's gate. This paper presents use of voltage feed-forward method which helps in suppressing effect of input line harmonics and disturbances and gives regulated output voltage. The converter is operating at a switching frequency of 140 kHz and behaviour of switching device is not taken into consideration. The converter has protection circuits like over voltage protection (OVP), over current protection (OCP) on input and outputs, under voltage protection (UVP) which protects from abnormal operating condition. The design and simulation results of the feed-forward technique with type-2 compensation and protection circuits are discussed.

Keywords: Forward Converter, Feed-Forward Method, Over Voltage Protection, Over Current Protection, Under Voltage Protection.

# I. INTRODUCTION

Switch mode power supplies have been used in applications where high efficiency and better reliability is of prime concern. The dcdc converter often categorised into isolated and non-isolated. In isolated dc-dc converter forward topology is preferred when output power demand is in the range of 150-200W [2]. Though isolated dc-dc converters provide galvanic isolation between input and output, there are instances where it's required to provide protection against short circuit or over load current, output over voltage and input under voltages and these may be drawback for the converter operation. Hence this paper explains a very effective techniques to overcome these drawbacks. The voltage feed-forward method with type-2 compensation is explained as it does not depend on load variation; instead, it reacts to control signals that have been predefined. It is used to lessen the abrupt changes in the input line voltage fluctuations cause changes in output voltage, which provides improved regulation by adjusting the duty cycle in accordance with change in input voltage [3]. The other protection circuits like over current, over voltage and under voltage are simulated and results of the same are presented. The simulation is carried out using LTspice software.

#### II. VOLATGE FEED-FORWARD METHOD WITH TYPE-2 COMPENSATION

To have a stable closed loop converter with appropriate performance, a properly designed compensator is required. Hence type-2 compensation with voltage feed-forward method is used, which gives fast dynamic response against the input voltage variations. The following parameters are considered to design type-2 compensation.

 $V_{in(min)} = 24; V_{in(max)} 42.5; V_o = 6V/12A; F_{sw} = 140 \text{kHz}; L_o = 30 \mu\text{H}; Co = 330 \mu\text{F}; V_{ref} = 2.5V; ESR = 10 \text{m}\Omega: P_O = 75W: \eta = 65\%$ 

A. Design of Type-2 Compensation.

1) Calculation of poles and zeros of power supply

$$F_{LC} = \frac{1}{2*\pi*\sqrt{L}*\mathcal{L}}$$
(1)

= 1.6 kHz

2) Zero caused by ESR of output capacitor

$$F_{ESR} = \frac{1}{2 * \pi * E \times R * C}$$
$$= 48.22 \text{ kHz}$$

(2)



International Journal for Research in Applied Science & Engineering Technology (IJRASET) ISSN: 2321-9653; IC Value: 45.98; SJ Impact Factor: 7.538 Volume 10 Issue X Oct 2022- Available at www.ijraset.com

(3)

(4)

(5)

(7)

3) Crossover frequency is chosen as  $\frac{1}{10}t\hbar$  of the switching frequency  $F_{co} = \frac{140 \times 1000}{10}$ 

4) Pole and Zero of compensator  $F_z = 0.75^* F_{LC} \label{eq:F_LC}$ 

= 1.2 kHz.

$$F_P = \frac{F_{SW}}{2}$$

5)

$$=\frac{140*1000}{10} = 70 \text{ kHz.}$$
  
Calculation of compensation resistor R<sub>C1</sub>

$$R_{C1} = \frac{Rf * Fear * Vasc * Fear}{Vin * Flo}$$

6) Calculation of compensation capacitor  $C_{C1}$ 

$$C_{Cl} = \frac{1}{2 * \pi * Roi * Fz} \tag{6}$$

7) Calculation of feedback capacitor 
$$C_{C2}$$

$$\mathbf{C}_{\mathbf{C}2} = \frac{\mathbf{I}}{\mathbf{I} \ast \pi \ast \mathbf{F} : \mathbf{c} \cdot \mathbf{I} \ast \mathbf{F} \mathbf{g}}$$

$$= 2.1 pF$$

# **III.OVER CURRENT PROTECTION (OCP)**

A switching power supply is designed to operate safely at a predetermined output power level. Output beyond nominal current should be avoided, but in case an overcurrent or short-circuit condition occurs, the power supply must have some means of protection circuit. Hence over current protection is designed to protect converter against such abnormal current operation as it decreases efficiency by increasing the losses.

#### A. Design of OCP

The full load current is 12A.Hence the OCP circuit is designed to trigger for 125% of load current.  $I_{in} = 15A (125\% \text{ of load current})$   $V_{ref} = 2.5V, f_{stw} = 140 \text{ kHz}, f_{sc} = 1.4 \text{ kHz}$   $C_1 = \frac{1}{2\pi f_s R_3}$  = 31.5nF  $R_{11} \& R_{12} = 15\text{K}\Omega$   $R_g = 10\text{K}\Omega$  limits the current to diode D1 nt limiting resistor to op-amp U1 &U2  $(I_{im} * R_g) * (1 + \frac{R_{12}}{R_{11}}) = 2.5\text{V}$  (9)



ISSN: 2321-9653; IC Value: 45.98; SJ Impact Factor: 7.538 Volume 10 Issue X Oct 2022- Available at www.ijraset.com

(11)

# IV. UNDER VOLTAGE PROTECTION (UVP)

The under voltage protection circuits help in protecting the converter against under voltage operation. When the converter operates below the designed voltage levels, the input current drawn will be higher and this will lead to further rise in losses and thereby temperature of the components. This operation decreases the efficiency of the converter. Hence it's necessary to design a under voltage protection circuit such that it should trigger when voltage falls below 80%-90% of the rated voltage.

#### A. Design of UVP

The design starts with the under voltage consideration as follows UVP = 80%-90% of input voltage

$$= 22V$$

B. Calculation of C1  $Fcut-off = \frac{FSW}{(6-10)}$ (10)

= 14 KHz

$$C1 = \frac{1}{2\pi * R7 * feat off}$$

Let  $R7 = 105K\Omega$ 

C1 = 108.24nF.

R5 and R6 Calculation

$$\operatorname{Vref} = \frac{\operatorname{Vin} \ast \operatorname{R5}}{\operatorname{R5} \ast \operatorname{R6}} \tag{12}$$

Let Vref = 5.1V and  $R5 = 105K\Omega$ 

$$5.1 = \frac{22 \cdot 105}{105 + R6}$$

 $R6 = 60 K \Omega$ 

#### V. OVER VOLTAGE PROTECTION (OVP)

These are the circuits designed to clamp the output voltages to a safe value, when the output voltage tries to rise above some predetermined value, thereby assuring the safety against over voltage conditions. To design OVP circuits an over voltage limit has been considered i.e 110% to 130% of actual output voltage.

A. Design of OVP	
R4 and R5 Calculation	
$Vref = \frac{Vout * R4}{RE + R4}$	(13)
Let $Vref = 2.5V$ and $R4 = 20K\Omega$	
$2.5 = \frac{5.5 \times 2D}{85 \pm 20}$	(14)
$\mathbf{R5} = 10.8 \mathbf{K} \mathbf{\Omega}.$	
Fcut-off = $\frac{F_{SW}}{(6-10)}$	(15)
= 14KHz	



ISSN: 2321-9653; IC Value: 45.98; SJ Impact Factor: 7.538 Volume 10 Issue X Oct 2022- Available at www.ijraset.com

Calculation of C1  $C1 = \frac{1}{2\pi * R2 * fout of f}$ Let R2 = 1Kf2 C1 = 11.36nF.

(16)

### VI.SIMULATION CIRCUITS AND RESULTS

The designed values have been used in simulating the each circuit. The losses of the switches are neglected and appropriate components selected from the LTspice software which can withstand the internal stresses. The Fig 1 shows the simulated circuit of forward converter with type-2 compensation. The voltage feed-forward method helps in achieving good and fast dynamic response. The output voltage and current waveforms is shown in Fig 2 and 3 respectively.



Fig 1 Simulation Circuit of Closed Loop Forward Converter





18A 16A

14A

12A-

10A-

8A

6A·

4A-

2A 0A

-2A 0.0ms

0.5ms

1.0ms

International Journal for Research in Applied Science & Engineering Technology (IJRASET) ISSN: 2321-9653; IC Value: 45.98; SJ Impact Factor: 7.538 Volume 10 Issue X Oct 2022- Available at www.ijraset.com

The Fig 4 shows the forward converter with over current protection circuit. When the load current exceeds the designed value, the voltage across R13 is set to high and shutdown pin is triggered and hence, the converter is protected by overcurrrent with the use of OCP circuit.



PULSE(0 12 0 1n 1n 1.785u 7.14u)

.tran 0 5m 0



Fig 4 Forward Converter with OCP

Fig 7 shows when the supply voltage is rated input and Fig 8 shows voltage across R8, which represents the shutdown pin voltage and it's low since input is rated.



ISSN: 2321-9653; IC Value: 45.98; SJ Impact Factor: 7.538 Volume 10 Issue X Oct 2022- Available at www.ijraset.com



Fig 7 Simulation Circuit of UVP



Fig 9 shows the when input voltage is 90% of minimum input voltage and Fig 10 shows the voltage across shutdown pin. The voltage is set to high interprets the converter is shutdown since it's drawing more current.







ISSN: 2321-9653; IC Value: 45.98; SJ Impact Factor: 7.538 Volume 10 Issue X Oct 2022- Available at www.ijraset.com



The simulated over voltage protection circuit is shown in Fig 11. The OVP is designed for 110%-130% of rated output voltage. When output exceeds this designed value, the shutdown pin is set to high and converter is shutdown.



Fig 11 Simulation Circuit of Over Voltage Protection Circuit





ISSN: 2321-9653; IC Value: 45.98; SJ Impact Factor: 7.538 Volume 10 Issue X Oct 2022- Available at www.ijraset.com

## VII. CONCLUSION

The voltage feed-forward method helps in achieving fast dynamic response of output voltage against input voltage variations. Apart from this, protection circuits also play vital role in the safe operation of the converter as it protects from over voltage or current damage. Hence it's necessary to deign protection circuit for better reliability and effective working of the converter.

#### VIII. ACKNOWLEDGMENT

Authors are thankful to the Management, Principal and Vice Principal, Dayananda Sagar College of Engineering and Centum Electronics Ltd. for their continuous support.

#### REFERENCES

- N. Lee, J. -Y. Lee, Y. -J. Cheon, S. -K. Han and G. -W. Moon, "A High-Power-Density Converter With a Continuous Input Current Waveform for Satellite Power Applications," in IEEE Transactions on Industrial Electronics, vol. 67, no. 2, pp. 1024-1035, Feb. 2020, doi: 10.1109/TIE.2019.2898584.
- [2] Youhao Xi and P. K. Jain, "A forward converter topology with independently and precisely regulated multiple outputs," in IEEE Transactions on Power Electronics, vol. 18, no. 2, pp. 648-658, March 2003, doi: 10.1109/TPEL.2003.809348.
- [3] A. Bhat, K. U. Rao, Praveen P K, B. K. Singh and V. Chippalkatti, "Multiple output forward DC-DC converter with Mag-amp post regulators and voltage feedforward control for space application," 2016 Biennial International Conference on Power and Energy Systems: Towards Sustainable Energy (PESTSE), 2016, pp. 1-6, doi: 10.1109/PESTSE.2016.7516488.
- [4] Guangjun Zhou, X. Ruan and Xuehua Wang, "Input voltage feed-forward control strategy for cascaded DC/DC converters with wide input voltage range," 2016 IEEE 8th International Power Electronics and Motion Control Conference (IPEMC-ECCE Asia), 2016, pp. 603-608, doi: 10.1109/IPEMC.2016.7512354.
- [5] J. Ge, Z. Zhao, L. Yuan and T. Lu, "Energy Feed-Forward and Direct Feed-Forward Control for Solid-State Transformer," in IEEE Transactions on Power Electronics, vol. 30, no. 8, pp. 4042-4047, Aug. 2015, doi: 10.1109/TPEL.2014.2382613.











45.98



IMPACT FACTOR: 7.129







INTERNATIONAL JOURNAL FOR RESEARCH

IN APPLIED SCIENCE & ENGINEERING TECHNOLOGY

Call : 08813907089 🕓 (24\*7 Support on Whatsapp)