



# **iJRASET**

International Journal For Research in  
Applied Science and Engineering Technology



---

# **INTERNATIONAL JOURNAL FOR RESEARCH**

IN APPLIED SCIENCE & ENGINEERING TECHNOLOGY

---

**Volume: 2**

**Issue: 1**

**Month of publication: January 2014**

**DOI:**

**[www.ijraset.com](http://www.ijraset.com)**

**Call: ☎ 08813907089**

**E-mail ID: [ijraset@gmail.com](mailto:ijraset@gmail.com)**

INTERNATIONAL JOURNAL FOR RESEARCH IN APPLIED SCIENCE  
AND ENGINEERING TECHNOLOGY (IJRASET)

# Experimental Investigation of Shell and Tube Heat Exchanger Using Bell Delaware Method

K Anand<sup>1</sup>, V K Pravin<sup>2</sup>, P H Veena<sup>3</sup>,<sup>1</sup>Thermal Power Engg., Dept. of Mechanical Engg. PDACE Gulbarga<sup>2</sup>Thermal Power Engg, VTU Regional Centre Gulbarga.<sup>3</sup>Dept of mathematics, Smt V G womens college, Gulbarga

**Abstract:** A heat exchanger is a device that is used to transfer thermal energy between two or more fluids, between a solid surface and a fluid, or between solid particulates and a fluid, at different temperatures and in thermal contact. Shell and tube heat exchangers in their various construction modifications are the most widespread and commonly used basic heat exchanger configuration in the process industries. In the present study, a water to water STHE wherein, hot water flows inside the tubes and cold water inside the shell is used to study and analyze the heat transfer coefficient and pressure drops for different mass flow rates and inlet and outlet temperatures, using Bell Delaware method. This method takes in to account heat transfer by bypass and leakage streams, hence minimizing losses and providing more realistic estimates of heat transfer and pressure drops.

**Keywords:** STHE, Heat transfer coefficient, shell & Tube heat exchanger, Pressure Drop, TEMA, Bell Delaware method.

## INTRODUCTION

Heat exchanger is a device of finite volume in which heat is exchanged between two media, one being cold and the other being hot. There are different types of heat exchangers; but the type widely used in industrial application is the shell and tube [1]. As its name implies, Shell-and-tube heat exchangers consist of a bundle of parallel tubes inside the shell that provides the heat-transfer surface separating the two fluid streams. The tube side fluid passes axially through the inside of the tubes; the shell-side fluid passes over the outside of the tubes. Baffles external and perpendicular to the tubes direct the flow across the tubes and provide tube support. Tube sheets seal the ends of the tubes, ensuring separation of the two streams. The process fluid is usually placed inside the tubes for ease of cleaning or to take advantage of the higher pressure capability inside the tubes [2].

The major components of this exchanger are tubes (tube bundles), shell, front end head, rear end head, baffles and tube sheets. The standard of the Tubular Exchanger Manufacturers Association (TEMA) describe various components in detail of shell and tube heat exchanger (STHE) [3].

In designing shell and tube heat exchangers, to calculate the heat exchange area, different methods were proposed [4][5]. Methods proposed for shell side design are as follows:

- 1) Kern Method
- 2) Donohue Method
- 3) Tinker Method
- 4) Devore's Method
- 5) Mueller Method
- 6) Bell's Method

## INTERNATIONAL JOURNAL FOR RESEARCH IN APPLIED SCIENCE AND ENGINEERING TECHNOLOGY (IJRASET)

- 7) Bell Delaware Method
- 8) Wills and Johnson Method
- 9) Taborek Method

And the methods proposed for tube side design are as follows:

- 1) Petukhov and Popov's Correlation
- 2) Mc Adam's Correlation
- 3) Petukhov and Kirrillov Correlation
- 4) Gnielinski Correlation

Among the above mentioned shell side design methods, Bell-Delaware is the most complete shell and tube heat exchanger design method. It is based on mechanical shell side details and presents more realistic and accurate results for the shell side heat transfer coefficient and pressure drop.

Bell developed a semi analytical method based on work done in the co-operative research program on shell and tube heat exchangers at the University of Delaware. His method accounts for major bypass and leakage streams. Bell Delaware method provides a manual check of shell side heat transfer coefficient and pressure drop values of a shell and tube heat exchanger. It gives more realistic estimates compared to Kern method, because leaks and bypass flows are considered [6][7].

### BELL DELAWARE METHOD

In the Bell Delaware method, the fluid flow in the shell is divided into a number of individual streams A through F as shown in Fig 1 and 2. [8][9]




FIG 1




FIG 2

There are five different shell side flow streams in a baffled heat exchanger:

- Stream A as shown in FIG 1 and 2 is the leakage stream in the orifice formed by the clearance between the baffle tube hole and the tube wall. The tube hole leakage stream represents the flow from one baffle compartment to the next that passes through the annular openings between the oversized holes for the tubes in the baffles and the outside of the tubes. The flow is driven by the pressure drop from one baffle compartment to the next. The leakage occurs through the diametral clearance between the diameter of baffle hole minus the outside diameter of the tube. If the tubes are expanded in to the baffles, then the diametral clearance is zero. If the diametral clearance becomes zero, then this bypass stream is completely eliminated.
- Stream B in FIG 1 is the main effective crossflow stream, which can be related to flow across ideal tube banks. This is the preferred flow in the baffled shell and tube heat exchanger.
- Stream C as shown in FIG 1 and 2 is the tube bundle bypass stream in the gap between the outside of the tube bundle and inner shell wall. The diametral clearance for this flow to pass through is equal to the shell internal diameter minus the outer tube limit diameter of the tube bundle. The bundle bypass stream is reduced by minimizing the diametral clearance and by installing pairs of sealing strips around the perimeter of tube bundle to block this flow path and thereby force the fluid back in to the tube bundle.

## INTERNATIONAL JOURNAL FOR RESEARCH IN APPLIED SCIENCE AND ENGINEERING TECHNOLOGY (IJRASET)

- Stream E in FIG 1 is the leakage stream between the outer edge of the baffle and inner shell wall. The diametral clearance is equal to the shell internal diameter minus the diameter of the baffle and is minimized by decreasing the construction clearance between the shell and the baffle to its feasible minimum.
- Stream F shown in FIG 2 is the bypass stream in flow channel partitions due to omissions of tubes in tube pass partitions. This stream only refers to those openings oriented in the direction of the fluid flow. Pass partition openings oriented normal to the flow path do not cause a bypass. This bypass stream thus only occurs in some multipass tube layouts and they can be eliminated by placement of several dummy tubes in each bypass lane to drive the fluid back in to the tube bundle.

Each of the above streams introduces a correction factor to the heat transfer correlation for ideal cross-flow across a bank of tubes.[10]

$$h_o = h_i * J_c * J_L * J_b * J_s * J_r$$

**J<sub>c</sub> - Baffle Cut Correction Factor:**

J<sub>c</sub> is the correction factor for baffle cut and spacing. This factor takes into account the heat transfer in the window and calculates the overall average heat transfer coefficient for the entire heat exchanger.

It depends on the shell diameter and the baffle cut distance from the baffle tip to the shell inside diameter.

- For a large baffle cut, this value may decrease to a value of 0.53
- It is equal to 1.0 for a heat exchanger with no tubes in the window
- It may increase to a value as high as 1.15 for small windows with a high window velocity.

**J<sub>l</sub> – Baffle Leakage Correction Factor**

J<sub>l</sub> is the correction factor for baffle leakage effects including tube -to- baffle and shell-to-baffle leakage (A- and E-streams in FIG 1). If the baffles are put too close together, then the fraction of the flow in the leakage streams increases compared with the cross flow.

J<sub>l</sub> is a function of the:


- ratio of total leakage area per baffle to the cross flow area between adjacent baffles
- ratio of the shell-to-baffle leakage area to the tube-to-baffle leakage area.

A typical value of J<sub>l</sub> is in the range of 0.7 and 0.8.

**J<sub>b</sub> – Bundle Bypass Correction Factor**

J<sub>b</sub> is the correction factor for bundle bypassing effects due to the clearance between the outermost tubes and the shell and pass dividers (C- and F-streams in FIG 1).

- For relatively small clearance between the outermost tubes and the shell for fixed tube sheet construction, J<sub>b</sub> = 0.90.
- For a pull-through floating head, larger clearance is required, J<sub>b</sub> = 0.7.
- The sealing strips (see figure 8.14) can increase the value of J<sub>b</sub>





## INTERNATIONAL JOURNAL FOR RESEARCH IN APPLIED SCIENCE AND ENGINEERING TECHNOLOGY (IJRASET)

FIG 3

$J_s$  – Unequal baffle Spacing Correction Factor:

The unequal baffle spacing correction factor accounts for the adverse effect of an inlet and outlet baffle spacing. Because of the nozzle spacing at the inlet and outlet and the changes in local velocities, the average heat transfer coefficient on the shell side will change.

The  $J_s$  value will usually be between 0.85 and 1.00.

$J_r$  – Laminar Flow Correction Factor:

In laminar flows, heat transfer is reduced by the adverse temperature gradient formed in the boundary layer as the flow thermally develops along the flow channel.  $J_r$  accounts for this effect.  $J_r$  applies if the shell-side Reynolds number,  $Re_s$ , is less than 100.

- If  $Re_s < 20$ , it is fully effective.
- This factor is equal to 1.00 if  $Re_s > 100$ .

Colburn  $j$ -factor

Colburn- $j$  factor is used in heat transfer in general and free and forced convection calculations in particular.

It is equivalent to  $(St \cdot Pr^{2/3})$  where  $St$  is Stanton number.

Colburn  $j$ -factor is a function of:

- Shell side Reynolds number based on the outside tube diameter and on the minimum cross section flow area at the shell diameter
- Tube layout
- Pitch size

In the present study, efforts have been made to study in detail Bell Delaware method and apply this method in calculating heat transfer coefficient, Reynold's number, pressure drops, overall heat transfer coefficient etc for a heat exchanger which has been designed and fabricated for our experimental investigations. The heat transfer fluid used is water. Hot water flows inside the tubes and cold water flows inside shell. At the end of the calculations, it is found that heat transfer coefficient (both shell side and overall) calculated using Bell Delaware method is much more than the one calculated using other methods, since Bell Delaware method

takes in to account, heat transfer even by bypass and leakage streams.

### FLUID PROPERTIES CONSIDERED

Shell side fluid properties:

$$\rho_s = 1000 \text{ kg/m}^3$$

$$\mu_s = 0.00088 \text{ N-s/m}^2$$

$$C_{ps} = 4.187 \text{ kJ/kg}^\circ\text{K}$$

$$K_s = 0.00098 \text{ kJ/s-m}^\circ\text{K}$$

Tube side fluid properties:

$$\rho_t = 1000 \text{ kg/m}^3$$

$$\mu_t = 0.00086 \text{ N-s/m}^2$$

$$C_{pt} = 4.187 \text{ kJ/kg}^\circ\text{K}$$

$$K_t = 0.00098 \text{ kJ/s-m}^\circ\text{K}$$

### HEAT EXCHANGER SPECIFICATIONS

In the present study, a stainless steel shell and tube heat exchanger is used to study the various parameters of the heat exchanger such as heat transfer coefficient, Reynolds's number, pressure drop, Overall heat transfer coefficient etc using water as a heat transfer medium. The design method used in calculating the parameters is Bell Delaware Method.[11][12][13]

Specifications of the heat exchanger are as follows:

Shell diameter ( $D_s$ )	0.2m
Tube inside diameter ( $D_i$ )	0.016m
Tube outside diameter ( $D_o$ )	0.01924m
Pitch ( $P_t$ )	0.03m
Length of shell ( $L_s$ )	0.8m
Length of tube ( $L_t$ )	0.825m
Length of baffle ( $L_b$ )	0.2m
Number of baffles ( $N_b$ )	4
Number of tubes ( $N_t$ )	18
Number of shell passes ( $n_s$ )	1
Number of tube passes ( $n_t$ )	2
Clearance ( $C$ )	0.01076m

## INTERNATIONAL JOURNAL FOR RESEARCH IN APPLIED SCIENCE AND ENGINEERING TECHNOLOGY (IJRASET)

Bundle to shell diametrical clearance ( $b$ )	0.028m	$\mu_s$ = Shell side fluid Viscosity (N-s/ $m^2$ ).
Shell to baffle diametrical clearance ( $s_b$ )	0.0254m	
Tube to baffle diametrical clearance ( $t_b$ )	0.0005m	$\mu_t$ = Tube side fluid viscosity (N-s/ $m^2$ ).
Nomenclatures:		
$S_m$ = Area of the shell side cross flow section ( $m^2$ ).		$\mu_w$ = Viscosity a wall temperature (N-s/ $m^2$ ).
$P_t$ = Tube pitch (m).		$C_{ps}$ = Shell side fluid heat capacity (kJ/kg $\cdot$ K).
$D_o$ = Tube outside diameter (m).		$C_{pt}$ = Tube side fluid heat capacity (kJ/kg $\cdot$ K).
$D_i$ = Tube inside diameter (m).		$K_s$ = Shell side fluid thermal conductivity (kJ/s $\cdot$ m $\cdot$ K).
$D_s$ = Shell inside diameter (m).		$K_t$ = Tube side fluid thermal conductivity (kJ/s $\cdot$ m $\cdot$ K).
$L_b$ = Baffle spacing (m)		$h_o$ = Shell side heat transfer coefficient (W/ $m^2\cdot$ K).
$L_s$ = Length of shell (m).		$h_i$ = Shell side ideal heat transfer coefficient (W/ $m^2\cdot$ K).
$L_t$ = Length of tube (m).		$N_b$ = Number of baffles.
$t_b$ = Tube thickness (m).		$N_t$ = Number of tubes.
$G_s$ = Shell side mass velocity (kg/ $m^2\cdot$ s).		$f$ = Friction factor.
$G_t$ = Tube side mass velocity (kg/ $m^2\cdot$ s).		$P_s$ = Shell side pressure drop (Pa).
$U_s$ = Shell side linear velocity (m/s).		$n_p$ = Number of tube passes.
$U_t$ = Tube side linear velocity (m/s).		$C$ = Clearance between tubes.
$m_s$ = Mass flow rate of the fluid on shell side (kg/s).		$b$ = Bundle to shell diametrical clearance.
$m_t$ = Mass flow rate of the fluid on tube side (kg/s).		$s_b$ = Shell to baffle diametrical clearance.
$\rho_s$ = Shell side fluid density (kg/ $m^3$ ).		$t_b$ = Tube to bundle diametrical clearance.
$\rho_t$ = Tube side fluid density (kg/ $m^3$ ).		$N_{ss}/N_c$ = Sealing strips per cross flow row.
$R_{es}$ = Shell side Reynolds number.		$D_{otl} = D_s - b$
$R_{et}$ = Tube side Reynolds number.		$= \{D_s - (2 \cdot L_c)\} / D_{otl}$
$P_{rs}$ = Shell side Prandtl number.		$F_c$ = Fraction of total number of tubes in a crossflow section.
$P_{rt}$ = Tube side Prandtl number		$J_c$ = Correction factor for baffle cut and spacing.
		$S_{sb}$ = Shell to baffle leakage area ( $m^2$ ).

## INTERNATIONAL JOURNAL FOR RESEARCH IN APPLIED SCIENCE AND ENGINEERING TECHNOLOGY (IJRASET)

$S_{tb}$ =Tube to baffle leakage area (m <sup>2</sup> ).
$F_{bp}$ = Fraction of the crossflow area available for bypass flow.
$S_w$ = Window flow area (m <sup>2</sup> ).
$N_c$ = Number of tube rows crossed in one crossflow section.
$N_{cw}$ =Effective number crossflow rows in window zone.
$P_c$ =Ideal cross flow pressure drop through one baffle space (Pa).
$P_w$ = Window zone pressure drop (Pa).
$R_L$ = correction factor for baffle leakage effect on pressure drop
$R_b$ = correction factor on pressure drop for bypass flow.

Calculation Of Shell Side Heat Transfer Coefficient Using Bell Delaware Method:

Experimental study is done on the shell and tube water / water heat exchanger and various parameters are calculated for different mass flow rates and at varying inlet and outlet temperatures. Calculations shown below are made for mass flow rate of .0267kg/s.

STEP 1: Calculate the shell side area at or near the centre line for one cross flow section  $S_m$ ,

$$S_m = L_b * [(D_s - D_{otl}) + \{(D_{otl} - D_o) * (P_t - D_o) / P_t\}]$$

$$S_m = .2 * [(2 - .172) + \{(.172 - .01924) * (.03 - .01924) / .03\}]$$

$$S_m = 0.017 \text{ m}^2$$

STEP 2: Calculate shell side mass velocity  $G_s$  and linear velocity  $U_s$ .

$$G_s = m_s / S_m$$

$$G_s = .020 / .017$$

$$G_s = 1.1764 \text{ kg/ m}^2\text{-s}$$

$$U_s = G_s / \rho_s$$

$$U_s = 1.1764 / 1000$$

$$U_s = .0011764 \text{ m/s}$$

STEP 3: Calculate shell side Reynolds number  $R_{es}$ .

$$R_{es} = (G_s * D_o) / \mu_s$$

$$R_{es} = (1.1764 * .01924) / .00088$$

$$R_{es} = 25.72$$

STEP 4: Calculate shell side Prandtl number  $P_{rs}$ .

$$P_{rs} = (C_{ps} * \mu_s) / K_s$$

$$P_{rs} = (4.187 * .00088) / .00098$$

$$P_{rs} = 3.7597$$

STEP 5: Calculate the colburn j factor  $j_i$ .

$$j_i = a_1 * \{ [1.33 / (P_t / D_o)]^a \} * (R_{es}^{a_2})$$

$$j_i = 1.36 * \{ [1.33 / (.03 / .01924)]^{.826} \} * (25.72^{-.657})$$

$$j_i = 0.1412$$

STEP 6: Calculate the value of the coefficient a.

$$a = a_3 / [1 + \{0.14 * (R_{es}^{a_4})\}]$$

$$a = 1.450 / [1 + \{0.14 * (25.72^{.519})\}]$$

$$a = 0.826$$

Where,  $a_1=1.360$ ,  $a_2 = -.657$ ,  $a_3 = 1.450$  and  $a_4 = .519$  for  $R_{es} < 100$ , are the coefficients to be taken from the table given in Kakac book for the obtained value of Reynolds number and pitch and layout.

STEP 7: Calculate the ideal heat transfer coefficient  $h_i$ .

$$h_i = j_i * C_{ps} * (m_s / S_m) * \{ (1 / P_{rs})^{(2/3)} \} * \{ (\mu_s / \mu_w)^{0.14} \}$$

## INTERNATIONAL JOURNAL FOR RESEARCH IN APPLIED SCIENCE AND ENGINEERING TECHNOLOGY (IJRASET)

$$h_i = .1412 * 4.187 * (.020 / .017) * \{ (1/3.7597)^{(2/3)} \} * \{ (.00088 / .00088)^{0.14} \}$$

$$h_i = 0.287 \text{ W/m}^2\text{K}$$

STEP 8: Calculate the fraction of total tubes in crossflow  $F_c$ .

$$\text{Consider, } = \{ D_s - (2 * L_c) \} / D_{out}$$

$$= \{ .2 - (2 * .05) \} / .172$$

$$= 0.581 \text{ rad}$$

$$F_c = (1 / ) * [ + (2 * ) * \sin\{\cos^{-1}( )\} - \{2 * \cos^{-1}( )\}]$$

$$F_c = (1 / ) * [ + (2 * .581) * \sin\{\cos^{-1}(.581)\} - \{2 * \cos^{-1}(.581)\}]$$

$$F_c = 0.695$$

Here  $L_c = 0.25 * .2 = 0.05$  for 25% baffle cut.

STEP 9: Calculate the correction factor for baffle cut and spacing  $J_c$ .

The value of  $J_c$  can be obtained from the *fig 2.33 of wolverine tube heat transfer data book Page No. 107* for the corresponding value of  $F_c$ .

$$J_c = 1.05$$

STEP 10: Calculate shell to baffle leakage area for one baffle  $S_{sb}$ .

$$S_{sb} = D_s * (s_b / 2) * [1 - \cos^{-1}( )]$$

$$S_{sb} = .2 * (.0254 / 2) * [1 - \cos^{-1}(.581)]$$

$$S_{sb} = 0.00556 \text{ m}^2$$

STEP 11: Calculate tube to baffle leakage area for one baffle  $S_{tb}$ .

$$S_{tb} = ( * D_o) * (t_b / 2) * N_t * [(1 + F_c) / 2]$$

$$S_{tb} = ( * .01924) * (.0005 / 2) * 18 * [(1 + .695) / 2]$$

$$S_{tb} = 0.0002305 \text{ m}^2$$

STEP 12: Calculate

$$(S_{sb} + S_{tb}) / S_m$$

$$(.00556 + 0.0002305) / .017$$

$$(S_{sb} + S_{tb}) / S_m = 0.349$$

$$S_{sb} / (S_{sb} + S_{tb})$$

$$0.00556 / (0.00556 + 0.0002305)$$

$$S_{sb} / (S_{sb} + S_{tb}) = 0.9601$$

STEP 13: Calculate the correction factor for baffle leakage effects  $J_L$ . The value of  $J_L$  can be obtained from the *fig 2.34 of wolverine tube heat transfer data book Page No. 108* for the corresponding value obtained in step 12 above.

$$J_L = 0.89$$

STEP 14: Calculate the fraction of the crossflow area available for bypass flow  $F_{bp}$ .

$$F_{bp} = (L_b / S_m) * (D_s - D_{out})$$

$$F_{bp} = (.2 / .017) * (.2 - .172)$$

$$F_{bp} = 0.3383$$

STEP 15: Calculate the correction factor for bundle bypassing effects due to the clearance between the outermost tubes and the shell and pass dividers  $J_b$ .

The value of  $J_b$  can be obtained from the *fig 2.35 of wolverine tube heat transfer data book Page No. 109* for the corresponding value of  $F_{bp}$ .

$$J_b = 0.96$$

STEP 16: The correction factors  $J_s$  and  $J_r$  are equal to 1 for  $Re_s \geq 100$ . But for  $Re_s < 100$ ,  $J_r$  can be obtained from *Fig. 2.37 of wolverine tube heat transfer data book Page No. 111*.



## INTERNATIONAL JOURNAL FOR RESEARCH IN APPLIED SCIENCE AND ENGINEERING TECHNOLOGY (IJRASET)

$$J_r = 0.88$$

STEP 17: Calculate the shell side heat transfer coefficient for the exchanger  $h_o$ .

$$h_o = h_i * J_c * J_L * J_b * J_s * J_r$$

$$h_o = 0.287 * 1.05 * 0.89 * 0.96 * 0.88$$

$$h_o = 0.258 \text{ W/m}^2\text{K}$$

Calculation Of Shell Side Pressure Drop Using Bell Delaware Method:

STEP 1: Calculate the number of tube rows crossed in one crossflow section  $N_c$ .

$$N_c = (D_s / P_{tp}) * [1 - \{(2 * L_c) / D_s\}]$$

$$N_c = (.2 / .02598) * [1 - \{(2 * .05) / .2\}]$$

$$N_c = 3.85 = 4$$

$$\text{Where, } P_{tp} = 0.866 * P_t$$

$$P_{tp} = 0.866 * .03$$

$$P_{tp} = 0.02598$$

STEP 2: Calculate the ideal cross flow pressure drop through one baffle space  $P_b$ .

$$P_b = [(2 * f_s * m_s^2 * N_c) / (s_m^2)] * [(\mu_s / \mu_w)^{0.14}]$$

$$P_b = [(2 * .000125 * .020^2 * 4) / (1000 * .017^2)] * [(.00088 / .00088)^{0.14}]$$

$$P_b = 1.38 * 10^{-6} \text{ Pa}$$

STEP 3: Calculate the window flow area  $S_w$ .

$$S_w = (D_s^2 / 4) * [\cos^{-1} \{ (1 - \sqrt{1 - (N_t / 8) * (1 - F_c) * D_o^2}) \}] - [(N_t / 8) * (1 - F_c) * D_o^2]$$

$$S_w = (.2^2 / 4) * [\cos^{-1} \{ .581 - \{ .581 * (1 - .581^2) \} \}] - [(18 / 8) * (1 - .695) * .01924^2]$$

$$S_w = 0.004 \text{ m}^2$$

STEP 4: Calculate the number of effective cross flow rows in window zone  $N_{cw}$ .

$$N_{cw} = (0.8 * L_c) / P_{tp}$$

$$N_{cw} = (0.8 * .05) / .02598$$

$$N_{cw} = 1.54$$

STEP 5: Calculate the window zone pressure drop  $P_w$ .

$$P_w = \{ [(26 * \mu_s * m_s) / (s_m * S_w)] * \{ (N_{cw} / (P_t - D_o)) + (L_b / D_w^2) \} \} + [m_s^2 / (2 * s_m * S_w)]$$

$$P_w = \{ \{ (26 * .00088 * .020) / (1000 * (.017 * .004)) \} * \{ (1.54 / (.03 - .01924)) + (.2 / .022^2) \} \} + [.020^2 / (2 * 1000 * .017 * .004)]$$

$$P_w = 0.037 \text{ Pa}$$

STEP 6: Estimate the correction factor on pressure drop for bypass flow  $R_b$ .

The value of  $R_b$  can be obtained from the fig 2.39 of wolverine tube heat transfer data book for the corresponding value of  $F_{bp}$ .

$$R_b = 0.78$$

STEP 7: Estimate the correction factor for baffle leakage effect on pressure drop  $R_L$

## INTERNATIONAL JOURNAL FOR RESEARCH IN APPLIED SCIENCE AND ENGINEERING TECHNOLOGY (IJRASET)

The value of  $R_L$  can be obtained from the fig 2.38 of wolverine tube heat transfer data book for the corresponding value obtained in step 12 above.

$$R_L = 0.78$$

$$U_t = G_t / \mu_t$$

$$U_t = 8.78 / 1000$$

$$U_t = .00878 \text{ m/s}$$

STEP 3: Calculate the tube side Reynolds number  $R_{et}$ .

$$R_{et} = (G_t * D_i) / \mu_t$$

$$R_{et} = (8.78 * .016) / .00086$$

STEP 8: Calculate the total pressure drop across shell  $P_s$

$$P_s = [(N_b - 1) * P_b * R_b] + (N_b * P_w) * R_L + [2 * P_b * R_b * \{1 + (N_{cw}/N_c)\}]$$

$$P_s = [(4 - 1) * 1.38 * 10^{-6} * .78] + (4 * 0.037) * .78 + [2 * 1.38 * 10^{-6} * .78 * \{1 + (1.54/4)\}]$$

$$P_s = 0.115 \text{ Pa}$$

Calculation Of Tube Side Heat Transfer Coefficient:

STEP 1: Calculate the tube side cross flow section area  $A_t$ .

$$A_t = \{(\pi * D_i^2) / 4\} * (N_t / 2)$$

$$A_t = \{(\pi * .016^2) / 4\} * (18 / 2)$$

$$A_t = .0018 \text{ m}^2$$

STEP 2: Calculate the tube side mass velocity  $G_t$  and

linear velocity  $U_t$ .

$$G_t = m_t / A_t$$

$$G_t = .0158 / .0018$$

$$G_t = 8.78 \text{ kg/m}^2\text{-s}$$

	Shell side (Cold Water)	R1	R2	R3	R4	R5
1	Mass flow rate (Kg/sec)	0.02	0.0257	0.0299	0.035	0.0397
2	Temperature at inlet (°C)	29.5	29.7	30.1	30.6	31.2
3	Temperature at outlet (°C)	29.4	32.2	33	33.5	33.9
4	Reynolds number	25.65	32.96	38.346	44.887	50.915
5	Prandtl number	3.76	3.76	3.76	3.76	3.76
6	Heat transfer coefficient (W/ m <sup>2</sup> *K).	0.26	0.286	0.302	0.32	0.336
7	Pressure drop (Pa)	0.115	0.169	0.215	0.278	0.343
8	Over all heat transfer coefficient	0.215	0.236	0.262	0.285	0.328

$$R_{et} = 163.35$$

## INTERNATIONAL JOURNAL FOR RESEARCH IN APPLIED SCIENCE AND ENGINEERING TECHNOLOGY (IJRASET)

STEP 4: Calculate the tube side Prandtl number  $P_{rt}$ .

$$P_{rt} = (C_{pt} * \mu_t) / K_t$$

$$P_{rt} = (4.187 * .00086) / .00098$$

$$P_{rt} = 3.674$$

STEP 5: Calculate the friction factor  $f$ .

$$f = \{(1.58 * \ln R_{et}) - 3.28\}^{-2}$$

$$f = \{(1.58 * \ln 163.35) - 3.28\}^{-2}$$

$$f = 0.0439$$

STEP 6: Calculate the tube side Nusselt number  $N_{ut}$ .

Nusselt number is calculated using Gnielinski Correlation

$$N_{ut} = \{(f/2) * (Re_t - 1000) * P_{rt}\} / \{1 + (12.7 * (f/2) * (P_{rt}^{1/4} - 1))\}$$

$$N_{ut} = \{(0.0439/2) * (163.35 - 1000) * 3.674\} / \{1 + (12.7 * (.0439/2) * (3.674^{1/4} - 1))\}$$

$$N_{ut} = -18.75$$

STEP 7: Calculate the tube side heat transfer coefficient

$$h_i$$

$$h_i = (N_{ut} * K_t) / D_i$$

$$h_i = (-18.75 * .00098) / .016$$

$$h_i = -1.15 \text{ W/m}^2\text{K}$$

Calculation Of Overall Heat Transfer Coefficient:

$$1/U_c = (1/h_o) + \{(D_o/D_i) * (1/h_i)\} + \{D_o * \ln(D_o/D_i)\} / (2k)$$

$$1/U_c = (1/.258) + \{(0.01924/.016) * (1/-1.15)\} + \{0.01924 * \ln(.01924/.016)\} / (2 * .00098)$$

$$U_c = 0.215 \text{ W/m}^2\text{K}$$

Calculation Of Tube Side Pressure Drop:

$$P_t = [\{(4 * f * L_t * n_p) / D_i\} + (4 * n_p)] * [(t * U_t^2) / 2]$$

$$P_t = [\{(4 * .0439 * .825 * 2) / .016\} + (4 * 2)] * [(1000 * .00878^2) / 2]$$

$$P_t = 1.006 \text{ Pa}$$

Tube side results for five sample readings are as below:

## INTERNATIONAL JOURNAL FOR RESEARCH IN APPLIED SCIENCE AND ENGINEERING TECHNOLOGY (IJRASET)

Shell side results for five sample readings are shown in the table below:

GRAPHS:




Fig a. Variation of Reynold's number w.r.t Flow rate on the Shell side




Fig b. Variation of Heat Transfer Coefficient w.r.t Flow rate on the Shell side

Tube side		R1	R2	R3	R4	R5
	(Hot Water)					
1	Mass flow rate (Kg/sec)	0.0158	0.0198	0.0262	0.0293	0.0365
2	Temperature at inlet (°C)	55.3	55.7	53.4	55.6	55.6
3	Temperature at outlet (°C)	37.1	42.4	44.2	45.2	46.8
4	Reynolds number	163.307	204.65	270.80	302.84	377.26
5	Prandtl number	3.674	3.674	3.674	3.674	3.674
6	Heat transfer coefficient (W/ m <sup>2</sup> ·K).	-1.288	-1.114	-0.914	-0.838	-0.691
7	Pressure drop (Pa)	1.006	1.433	2.256	2.715	3.928




Fig c. Variation of Pressure drop w.r.t Flow rate on the Shell side

## INTERNATIONAL JOURNAL FOR RESEARCH IN APPLIED SCIENCE AND ENGINEERING TECHNOLOGY (IJRASET)




Fig d. Variation of Reynold's number w.r.t Flow rate on the Tube side



Fig g. Variation of Overall Heat Transfer Coefficient w.r.t Flow rate of the Exchanger.




Fig e. Variation of Heat Transfer Coefficient w.r.t Flow rate on the Tube side




Fig f. Variation of Pressure drop w.r.t Flow rate on the Tube side.

### CONCLUSION:

The shell and tube heat exchanger is analyzed using Bell Delaware method and heat transfer coefficient, Reynold's number, pressure drops, overall heat transfer coefficient etc are calculated for various mass flow rates and the results are shown in the graphs above. It is emphasized that, shell side heat transfer coefficient increases with increasing mass flow rate. Also the shell side pressure increase rapidly with increasing flow rate.

Also it was found that the overall heat transfer coefficient of the shell and tube heat exchanger increases with increasing flow rate. This heat transfer coefficient is much more when calculated using Bell Delaware method than the one calculated using other methods, since Bell Delaware method takes in to account, heat transfer even by bypass and leakage streams.

### REFERENCES:

- [1]Ebiato, CE and Eke G B, "Performance Analysis of Shell and Tube Heat Exchangers: A case study "Department of Mechanical Engineering, Faculty of Engineering, University of Port Harcourt, Port Harcourt, Nigeria. Journal of Emerging trends in engineering and applied sciences(JETEAS) 3(5):899-903.
- [2]The Fundamentals of Heat Exchangers, by Dean A. Bartlett
- [3]Tubular Exchanger Manufacturers Association, "Standards of the Tubular Exchanger Manufacturers Association," 7th Ed., TEMA, New York (1988).



---

## INTERNATIONAL JOURNAL FOR RESEARCH IN APPLIED SCIENCE AND ENGINEERING TECHNOLOGY (IJRASET)

---

- [4] Mauro A. S. S. Ravagnani<sup>1</sup>, Aline P. Silva<sup>1</sup> and Jose A. Caballero<sup>2</sup> "Optimal Shell and Tube Heat Exchangers Design" State University Of Maringa<sup>1</sup>University Of Alicante<sup>2</sup>, Brazil<sup>1</sup>, Spain<sup>2</sup>.
- [5] Sadik kakac, "Heat Exchangers Selection, Rating and Thermal Design", 2002.
- [6] Wolverine Tube, INC, Single phase shell side flows and heat transfer.
- [7] Wolverine Tube Heat Transfer Data book, Delaware method for shell side rating and shell and tube heat exchangers.
- [8] D. Gulley, Gulley & Associates, Tulsa, Oklahoma, More accurate exchanger shell side calculations,
- [9] Sandeep K. Patel, Professor Alkesh M. Mavani"Shell & tube heat exchanger thermal designWith optimization of mass flow rate and baffle spacing" International Journal of Advanced engineering Research and Studies IJAERS/Vol .II/Issue I/Oct.-Dec.,2012/130-135
- [10] John E Edwards, "Design and Rating Shell & tube heat exchanger"
- [11]Bell k. j. delaware method for shell-side design, in: serth r.w., process heat transfer principles and applications, elsevier science & technology books, 2007, pp. 145.
- [12]Tinker t. (1951) "shell-side characteristic of shell-and-tube heat exchangers", parts ii, iii, and in:proceedings of general discussion on heat transfer, institute of mechanical engineers and American society of mechanical engineers, london, new york,pp. 89.
- [13]Mukherjee R, Effective design Shell and Tube Heat exchangers, Chemical Engg Progress,(1998), 1-8.
- [14]Comparative Analysis of Finned Tube and Bared Tube Type Shell and Tube Heat Exchanger ShivKumar Rathore, Ajeet Bergaley, International Journal of Engineering and Innovative Technology (IJEIT)Volume 2, Issue 1, July 2012, ISSN: 2277-3754 ISO 9001:2008 Certified.



10.22214/IJRASET



45.98



IMPACT FACTOR:  
7.129



IMPACT FACTOR:  
7.429



# INTERNATIONAL JOURNAL FOR RESEARCH

IN APPLIED SCIENCE & ENGINEERING TECHNOLOGY

Call : 08813907089  (24\*7 Support on Whatsapp)