



# **iJRASET**

International Journal For Research in  
Applied Science and Engineering Technology



---

# **INTERNATIONAL JOURNAL FOR RESEARCH**

IN APPLIED SCIENCE & ENGINEERING TECHNOLOGY

---

**Volume: 8      Issue: XII      Month of publication: December 2020**

**DOI: <https://doi.org/10.22214/ijraset.2020.32494>**

**[www.ijraset.com](http://www.ijraset.com)**

**Call:  08813907089**

**E-mail ID: [ijraset@gmail.com](mailto:ijraset@gmail.com)**

# Physical and Thermodynamic Analysis of the Geothermal Power Systems

Sandhineni Sai Chandu<sup>1</sup>, Saripally Rahul Tej<sup>2</sup>

<sup>1, 2</sup> B. Tech Student, Department of Mechanical Engineering, Sreyas Institute of Engineering and Technology, Bandlaguda, Hyderabad – 500068

**Abstract:** *The Main conceptualization of this examination is to focus on the different liquids and properties blocking the Geothermal Power Systems. The quantity of plants has been expanded quickly in the previous few years. The primary issue with Geothermal Systems is the effectiveness of which the pace of electricity is delivered. This research conceptualizes to stimulate and dissect the different presumptions of the particular geothermal systems which are basically utilized. It includes the different boundaries and properties in both physical and chemical methods of the system to separate them and discover the primary issues emerging in these components when they are utilized in the system. Basically, this spotlights mediocre efficiency rate systems, such as Underground Thermal Energy Storage and Hybrid Ground Source Heat Pump. It contains chemical balances, work efficiencies, ideas that principally centre to improve the overall rate. It additionally incorporates components of geothermal chemical agents and their kinetic reactions with the other kind of materials with certain reasonable changes and varieties and to make them more proficient when working in the geothermal power systems which may bring about making them a certain different progressive chemical agent. Eventually, it for the most part centres around the consequences of different thermodynamic efficiencies and coefficient of performances which must become about for every single different geothermal system to value out them in their own categories.*

**Keywords:** Numerical Simulation, Go-Kart Chassis, Vibrational Behaviour, Resonance, Structural Rigidity, Reliability, Explicit dynamics, Catia V5, ANSYS 14.5 Workbench.

## I. INTRODUCTION

The world necessities to move far away from fossil and fuels because of the expansion in the contamination of both air and water which is making a great deal to this planet earth. An unnatural weather change has become a significant catastrophe for this planet which must be killed at the earliest opportunity, for these significant issues sustainable power sources are the central issue to be seen later on just as in the present the main thing with regards to sustainable power sources is the effectiveness at which they produce. Sustainable power sources contain many types of energies that can be used in everyday existence with no harm to human instinct, for instance, solar energy, wind energy, geothermal energy, tidal and wave energy [1]. Geothermal energy has become a significant reasonable thing with a low measure of yield emerging from it yet working in little and various pieces of the world in a fundamental manner geothermal energy characterizes the energy emerging from the earth as land heat. The lower the deck goes into the earth the higher the temperature gets typically, the temperature at the core i.e. at the centre of the earth is almost 6000 degrees centigrade. Significantly geothermal energies happen close to the hot springs and in the spots where rocks height is high, and the temperature of the stones is more practically identical to the next sea-level spots. In this exploration, the fundamental physical and chemical properties or characteristics are examined about geothermal energy and its prospects which can change from various sorts of systems placed in the plant. This examination recognizes and confirms the boundaries and checks its different outcomes which may be influencing the product. This exploration basically centres around taking parameters and factors and considering them to change the system that we are utilizing in this examination each factor suggests various outcomes for each plant. Thus, that is in the event that each factor and each parameter must be thought about making a superior geothermal plant. Every single electricity produced plant predominantly centres around its effectiveness the rate at which the power or the electricity is produced, this examination additionally incorporates the thermodynamics of two various types of geothermal frameworks i.e., underground geothermal system and hybrid geothermal heat pump system. These two frameworks are significantly utilized in this world and produce a high pace of greatest productivity right now.

The ground-coupled heat pump-based energy frameworks is utilizing geothermal underground energy for space heat and cooling. This paper plays out a thermodynamic examination of a closed-loop heat pump-based heating system coupling two external heat "reservoirs" with various variable features. The heat "sink" is the heated space that asks for a heating rate capacity of the environmental temperature and the heat "source" is the soil with a variable temperature as expected.

Another significant thing that impacts the productivity of a geothermal plant is the liquids utilized in the geothermal plant the boundaries influencing them the rate at which they should work and the results of the liquids and the aging and de-aging of the liquids and their life focuses. The chemical balances used in it, the kinetics placed in the fluids and their natural habitat throughout their life. It likewise incorporates the gases utilized in it and their varieties which may have any kind of effect on the efficiency and coefficient of performance. It finishes up by exhibiting the distinctions in the liquids, gases, and properties inferred in the geothermal power systems. Geothermal Plants should be arising out of now onwards because of the high expansion in the world's covering temperature. It is difficult to go to the mantle part of the earth however it contains more measure of temperature when contrasted with the earth's crust [2]. By making this exploration it envisions us that the efficiency and performances of the power systems in the sustainable power area can be overseen and continue to give the most noteworthy proficiency. The world must move the emphasis on different kinds of sustainable power sources, to make them more noticeable ones contrasted with the fossil and fuels which are utilized more nowadays.

## II. PHYSICAL AND CHEMICAL ATTRIBUTES OF GEOTHERMAL POWER SYSTEMS

### A. Water Phase Relationships and Critical Point

A Prior to discussing the phases of water, which depend to some extent on temperature and heat (thermal energy) accessible, a short conversation on the two qualities is beneficial to stay away from likely visible confusion. Temperature gauges how hot or cold an object is. The hotter the object, the quicker its atoms vibrate; along these lines, the item will contain higher interior heat or thermal energy. Temperature is estimated in degrees on different scales, for example, Celsius or Kelvin, yet heat or thermal energy is estimated in joules or calories. To show the distinction among temperature and warmth, think about espresso in a cup at 90°C and water in a hot bucket at 40°C. espresso is hotter than the water in the hot bucket, yet the hot bucket water contains considerably more heat or thermal energy because of its more prominent mass [3]. At the end of the day, if the water in the hot bucket and water in the espresso cup began at a similar temperature of 20°C, for instance, significantly more thermal energy would be expected to raise the temperature of the water in the hot bucket to 90°C than for espresso cup considering the more prominent mass of the water in the hot bucket. Water has three fundamental stages—ice (solid), fluid, and vapor. Of the three principal periods of water, each stage has its own specific heat, with liquid water having the highest (the specific heat of supercritical water is variable depending on the conditions of temperature and pressure). Specific heat is the heat needed to change the temperature of a unit mass of a single mass by a unit mass of temperatures, for example, 1°C or 1 K; in this way, units for Specific heat are energy per unit mass per degree. The specific heat of ice is about 2.1 J/g×K, implying that it takes about 2.1 joules of energy per gram of ice to rebuild the temperature by 1 K. For the water, the specific heat is about twofold that of ice or about 4.2 J/g×K, and for steam the worth resembles that of ice at about 2.1 J/g×K. The distinctive specific heat limits of each stage are reflected by the lope in the adjustment in temperature of the single stage in Figure 4.1. Note the gentler slant for liquid water contrasted with ice and steam, implying that it takes more heat to change the temperature of fluid water than for ice and steam.




Figure 4.1: Phase change diagram for water illustrating changes in temperature as a capacity of added heat (energy), as heat is added, temperature increments. Where two phases are available, the temperature stays consistent until just one phase remains. Note that the higher specific heat for water is reflected by the gentler slant contrasted with that of steam and ice. Steam contains a high measure of latent heat energy that turns out to be somewhat accessible to do work.



During the progress between one phase and the following, the temperature remains steady, as the additional heat goes to driving the phase change (Figure 4.1). The heat needed to drive a phase change is called latent heat and fluctuates relying upon the kind of phase change. For example, the latent heat of fusion (melting) of ice is 80 calories per gram (or 336 joules per gram), whereas the latent heat of vaporization (liquid water to steam) is a considerable 540 calories per gram (or about 2268 joules per gram) (Figure 4.1). With the end goal for water to move from a low energy state, for example, ice, to a high energy state, for example, steam, it must absorb energy (latent heat) from its current circumstance. In like manner, to go from higher energy steam to bring down to lower energy liquid water, energy must be given up to the climate. From a geothermal viewpoint, this implies that a portion of that energy becomes available to do work as steam is condensed to liquid water. This work is utilized to turn turbine sharp edges and drive an electrical generator.

The Figure 4.1 illustrates changes in temperature of the various phases of water at constant pressure, however for geothermal purposes, it is additionally important to see water phase changes as a component of both temperature and pressure (Figure 4.2). The negative incline of the ice–fluid limit in Figure 4.2 mirrors the volume expansion that happens after freezing. All in all, at constant temperature ice, will dissolve with an expansion in pressure. This outcomes in the liquid field growing at higher pressure. The other point is the critical point, which happens at about 374°C and 22 MPa or 220 bars (218 atmospheres). At temperatures and pressure over the critical point, a qualification among liquid and vapor stops to exist, and water has properties of both liquid and vapor, for example, the capacity to diffuse like a vapor for increased permeability but also the ability to dissolve minerals like a liquid (all in all, possibly being corrosive or hostile to hardware). Some especially hot geothermal systems, for example, those in Iceland, most likely contain supercritical fluids in their deeper segments; if these were gotten to and created, their capacity yield would be 5 to multiple times that of a well tapping a subcritical reservoir.




Figure 4.2: Stage chart for water. Note the negative slant of the ice–liquid water the limit which favors the fluid stage at a higher weight and the district for supercritical water above 374°C and 221 bars.

### B. Liquid Dominated Geothermal Systems

Liquid-dominated systems are the most widely recognized sorts of hydrothermal systems created for power generation and direct use. The fluid is in the liquid state because the fluid remains below the boiling point curve with depth. The boiling point increments because of the increase in pressure, as outlined in Figure 4.3. In such frameworks, the liquid doesn't start to boil or blaze until it ascends to bring down pressure and converges the curve, at which point the fluid cools along the curve with an extra deduction in pressure or deepness [4]. Furthermore, with pressure, the boiling point of geothermal liquids is likewise impacted by broken up solids and gases. increasing amounts of dissolved solids will build the boiling point, while expanding dissolved intensity of non-condensable gases, for example, CO<sub>2</sub> will bring down the boiling point (Figure 4.3).




FIGURE 4.3 Changes in temperature of the boiling point of water with deepness. dissolved solids, for example, NaCl, will expand the boiling point temperature, while disintegrated gases, for example, CO<sub>2</sub>, will bring down the boiling point.

### C. Temperature Range of Fluids

The temperature of fluids goes from <150°C to about 450°C in the absolute most smoking brine water systems in the Imperial Valley of southeastern California. For power creation, liquids are commonly more prominent than about 125°C yet can be as low as about 80°C, for example, at Chena Hot Springs, binary geothermal power plants are normally in the scope of 115 to 185°C, single-flash plants from around ~155 to ~220°C, and two-fold or triple-fold flash plants above <220°C. Direct-use frameworks are commonly in the scope of 40 to 110°C.


### D. Fluid Compositions

Liquid syntheses can be gathered into three fundamental classes:


- 1) Neutral chloride,
- 2) Acid sulfate, and
- 3) Saltwater.

Neutral chloride systems are probably the most usually overworked; they have close neutral pH (weakly acidic to feebly alkaline, pH ~6 to ~8.5). Totally dissolved solids (TDS) range from <1000 ppm to around 10,000 ppm. Due to the amiable synthetic make-up of the liquids in these systems, they are probably the simplest to create. The liquids are noncorrosive to gear, and encourages of silica or carbonate scale, which can lessen stream in wells and pipelines, are genuinely simple to oversee. Basically, the entirety of the created geothermal fields uses geothermal liquids of this sort.

Acid sulfate liquids, as the name infers, are acidic (pH regularly <4 and at times <1) and are wealthy in disintegrated sulfate. Such liquids usually happen close to the occasions of dynamic volcanoes where magmatic fumes wealthy in SO<sub>2</sub> and HCl respond to deliver acidic conditions. In particular, SO<sub>2</sub> gas disproportionate (goes through a redox reaction where SO<sub>2</sub> is at the same time oxidized and decreased) to shape sulfuric acid (HS<sub>2</sub>SO<sub>4</sub> - oxidized) and hydrogen sulfide (H<sub>2</sub>S-diminished) as shown by the accompanying reaction:





The H<sub>2</sub>S can additionally respond with close surface oxygen to likewise create sulfuric acid:



All things considered; these systems can be exceptionally destructive to hardware. Even though temperatures and enthalpy can be very high (>220°C), they are either not created or require corrosive balance techniques. For instance, the high-temperature segment of the Miravalles geothermal well field in Costa Rica, which is found nearest to the flanks of a functioning volcano of liquid magma requires an infusion of dilute sodium hydroxide (NaOH) to help kill the pH and diminish corrosion of good housings and surface gear.

Brine solution geothermal systems are those that have more than about 3.5% (or 35,000 ppm) absolute dissolved salts (which is practically identical to that of seawater). Some geothermal brines waters are hypersaline, for example, those in the Salton Trough of southeastern California. The Salton Trough incorporates the Salton Sea, Brawley, Heber, and East Mesa geothermal fields, whose liquids contain as much as 26 wt% total dissolved solids (TDS) with temperatures as high as 365°C at depth of 2 to 3 km.

The high brine water content outcomes from the geothermal liquids experiencing and dissolving evaporite rock layers (comprising principally of gypsum with halite). The neighboring Cerro Prieto geothermal field toward the south in Mexico is additionally important for the Salton Trough. The geothermal liquids there, nonetheless, are not hypersaline on the grounds that beds of evaporite are missing or insignificantly created in the stone segment. The brine liquids are additionally unassumingly acidic on the grounds that the dissolution of gypsum forms sulfuric acid and a base calcium hydroxide as appeared by the reaction below:




Since sulfuric acid is a solid corrosive and calcium hydroxide is a moderate base, the subsequent arrangement isn't pH neutral yet acidic. Subsequently, these salt waters can bring about both extensive corrosion of gear and clog because of the development of scale in wells and pipelines. The as of late opened 49.9-MWe Hudson Ranch - I geothermal plant gets to 350°C hypersaline saltwater containing more than 200,000 ppm TDS, including high centralizations of lithium (Li), manganese (Mn), and zinc (Zn). To keep scaling of equipment from the hypersaline saltwater at the Hudson Ranch office, seed material is added to the leftover liquid after flashing. The supersaturated solids of the hypersaline saltwater at that point encourage on the seed material instead of on the surfaces of the flash chamber and pipelines. The subsequent slurry is shipped off a chemical handling plant where the dissolved solids are generally eliminated preceding reinjection to try not to obstruct infusion wells and reservoir permeability. The arrangement is to ultimately recuperate Li, Mn, and Zn from the isolated disintegrated solids for prepared business sectors in battery and steel production. An extra feature of the Hudson Ranch - I power plant is that its 49.9-MWe yield is essentially given by only two of three production wells. Indeed, just each well is required in turn, making these the absolute most remarkable delivering geothermal wells on the planet.

#### E. Low – Sulfidation Alteration

Because of the near-neutral pH and alkali chloride arrangement of the liquids, the style of adjustment (kind of minerals shaped) in wallrocks is represented basically by temperature, instead of the more broad physical and compound changes related with modification of the high-sulfidation type. Geothermal up-flow zones indicate porous regions where hot liquids are effectively rising and are beneficial focuses on delivering geothermal wells with temperatures going from about 180°C to about 360°C. Real liquid pathways, for example, cracks and faults, generally contain minerals of quartz, adularia, and calcite. Wallrocks connecting the liquid pathways are supplanted by factor combinations of minerals that are steady contingent upon states of temperature and pressure, including epidote, K-feldspar (adularia), chlorite, actinolite, calcite, and albite. At the upper-temperature end (>~280°C), minor garnet, biotite, and diopside can likewise happen. Modified wallrocks in this area normally have a greenish tone mirroring the green shade of chlorite, epidote, and conceivable actinolite (at the upper-temperature range), which regularly supplant essential mafic minerals and plagioclase. For the financial geologist searching for stores of gold and silver in fossil geothermal systems, this sort of wallrocks adjustment is alluded to as propylitic. For current or dynamic geothermal systems, the propylitic zone normally denotes the geothermal sweet spot or supply locale for systems overwhelmed by close unbiased pH antacid chloride liquids. At shallower depths and cooler temperatures, propylitic adjustment generally offers approaches to fluidly adularized and silicified rock, commonly communicated as exceptionally fine-grained adularia and microcrystalline silica that flood and accelerate in the pores of the stone [5]. This flooding along these lines can crush essential permeability, and yet makes the stone-hard and fragile, which can promote secondary or fracture permeability when exposed to thermal or structural stresses.

If liquids ascending along breaks arrive at the surface, underground aquifer travertine or silica sinter can shape, depending upon the temperature of liquids ascending from depths, as seen in the Figure 4.4. Where the geothermal store is generally cool, at temperatures not exactly about 140°C, the mineral travertine (a united type of calcite) is ordinarily kept. Travertine-type underground aquifers might be cool enough to absorb (yet not generally!). If the liquids are sultrier, in any case, the travertine would be stored at profundity since calcite turns out to be less dissolvable with expanding temperature, because of its retrograde dissolvability. The development of calcite can be communicated by the following reaction:





(Calcite)

The retrograde solvency of calcite happens on the grounds that CO<sub>2</sub> is less solvent in high-temperature arrangements than in low-temperature arrangements so it will in general get away. This drives the above response to one side, as anticipated by Le Chatlier's principle, advancing the precipitation of calcite.



Figure 4.4 View of silica sinter terrace at Steamboat Hills close to Reno, Nevada, as it glanced in 2017. Water-fume discharging gap strikes north and gave sinter-storing boiling water as of late as the mid-1980s.

On the off chance that liquid store temperatures surpass  $200^{\circ}\text{C}$ , at that point silica sinter ordinarily saved as boiling water is released at the spring. This is on the grounds that silica has prograde dissolvability, implying that as temperature builds more silica can be disintegrated in the arrangement. As the temperature cools, which happens most drastically at or close to the surface, the disintegrated silica accelerates. Where temperatures are less, for example, on the edges of the up-flow zones or in revive locales of downflowing liquids, wallrocks can be adjusted to a combination of muds and fine-grained micas, for example, illite and sericite. This sort of adjusted stone, not at all like propylitic and silicic modified zones, is generally delicate and has a general whitish shading that makes the stone obvious and hence a significant investigation instrument. The improvement of dirt, for example, kaolinite, or fine-grained micas is essentially due to hydrolytic modification where hydrogen particles of the geothermal liquid supplant cations of silicate minerals to create muds or fine-grained micas. This is represented in the compound response beneath, where K-feldspar is changed over to kaolinite:



At slightly higher temperatures ( $>160^{\circ}\text{C}$ ), fine-grained micas, such as illite or sericite, would form instead of kaolinite.

#### F. High – Sulfidation Alteration

The high-sulfidation sort of adjustment is described by minerals stable at high temperatures ( $180^{\circ}$  to  $380^{\circ}\text{C}$ ) and under acidic conditions (pH ordinarily  $<3$ , occasionally  $<1$ ). Average nonsulfide minerals present incorporate alunite (hydrated potassium aluminium sulfate,  $\text{KAl}_3(\text{SO}_4)_2(\text{OH})_6$ ) and aluminous-rich dirt's, for example, kaolinite and dickite, anhydrite (calcium sulfate,  $\text{CaSO}_4$ ), and locally native sulfur. Sulfide minerals can incorporate pyrite and sulfur-rich, copper-bearing minerals, for example, enargite. As noted above, such zones are restricted proximal to vent territories of dynamic volcanoes, where magmatic gases, for example,  $\text{SO}_2$  and  $\text{HCl}$ , are high. As sulphur dioxide experiences close surface groundwater, it disproportionate:



The  $\text{H}_2\text{S}$  can additionally respond with oxygen in the air or at shallow depths to likewise deliver sulfuric acid:  $\text{H}_2\text{S} + 2\text{O}_2 \rightarrow \text{H}_2\text{SO}_4$

Because of the acidic conditions, encompassing wallrock is usually drained of cation compounds (K, Na, Ca, and Mg), leaving a silica build-up ordinarily alluded to as vuggy quartz. Not at all like low-sulfidation adjustment, where silica can be added to the stone, making for a hard and conceivably impermeable stone (pore space loaded up with silica), vuggy quartz can be very permeable and porous, prompting great liquid course.






FIGURE 4.5 Schematic cross-area delineating the parallel progress from high sulfidation modification close to the vent district of a functioning volcano (volcanic-aqueous frameworks) to low sulfidation change on the flanks of the fountain of the volcano (geothermal systems). The finger-formed zones beneath the fountain of liquid magma vent/pit lake speak to molten interruptions that are the heat source for both the geothermal and volcanic-aqueous systems. Likewise portrayed are districts of various styles of mineralization that structure at various degrees of depths notwithstanding the various types of aqueous modification, high sulfidation, and low sulfidation, found at and close to the surface.

Even though liquids related with high-sulfidation adjustment ordinarily have high temperatures and enthalpy substance, they are not typically evolved because of their destructive nature. In any case, the edges of such systems can progress into regions described by near-neutral pH alkali chloride arrangement and related adjustment (Figure 4.5).

#### G. Adjustment Associated with Hypersaline Brine Systems

Adjustment related to hypersaline brine solution systems, for example, the geothermal fields in the Salton Trough in southern California, is of the low-sulfidation type. Rocks in the geothermal stores there are propylitically modified and contain boundless epidote and chlorite. In this system, veins of epidote (alongside quartz and pyrite) change mineralogy as a component of profundity and temperature. Calcite happens with epidote above depths of 2200 mts, antacid feldspar (adularia) at depths somewhere in the range of 1800 mts and 2950 m, and actinolite under 2890 mts. At the most profound levels, depths of 3000 to 3280 mts, aqueous pyroxene happens. Fractional disintegration of evaporite beds (gypsum in addition to halite) at profundities of 1 to 3.4 km has made neighbourhood arrangement breakdown of interbedded shale layers. Such volume compression can prompt expanded permeability, in any event locally, and improved liquid dissemination. Most hypersaline saltwater frameworks have restricted or no surface articulation partially because of the thick, saline-rich nature of the geothermal liquid, making it hard for them to arrive at the surface. In the Salton Trough district, the geothermal supplies are likewise overlain by impermeable cap rocks comprising of shales and evaporite stores and deltaic sandstones [6]. The precipitation of anhydrite and calcite from descending permeating water stopped up pores in the deltaic sandstone and diminished penetrability. Where liquids do arrive at the surface, through confined breaks in the generally impermeable cap rocks, earth rich mud pots structure locally, reflecting both the low volume of stream and acidic nature of significant level geothermal liquids. The acidic character of these high-level geothermal liquids is presumably because of boiling arrangements at depths offering to ascend climbing H<sub>2</sub>S, which oxidizes to sulfuric acid (steam-warmed adjustment).

#### H. Vapor Dominated Geothermal Systems

These are the diamonds of the geothermal world on the grounds that the enthalpy or heat energy used to deliver power isn't apportioned among fluid and vapor; all liquid mass is as dry steam and goes to the turbine. Shockingly, the systems are the most uncommon topographically on the grounds that they require exceptional geologic conditions to create (as depicted in the part underneath). The two biggest created vapor dominated systems on the planet are The Geysers in northern California and Larderello in Italy. These two systems together produce around 1700 MWe, or about 14% of the world's geothermal force limit starting in August 2015. Around 10 years prior, these two vapor-ruled systems involved about 25% of the world's geothermal electrical force limit, however, the rate has declined principally because of new flash and binary systems coming on the web and the moderately static yet economical creation at The Geysers and Larderello.



Development and Rarity – Huge vapor-dominated systems, for example, The Geysers, are geographically uncommon for a few reasons. To start with, these systems regularly start as fluid dominated systems and advance into vapor-dominated ones. For this to occur, an intense heat source and low paces of recharge are needed; as the fluid heats up, a steam cap creates over the long run (on the request for a huge number of years). Second, all together for the steam cap to develop, some spillage of steam to the surface must happen. Without spillage, the framework would pressurize to the point that boiling would stop, and a consistent state condition would create comprising of a stale steam cap overlying a nonboiling fluid zone. With some surface spillage, be that as it may, the steam cap develops as the bubbling fluid zone brings due down to dissipation. The greater part of the up-flow steam most likely consolidates on the edges of the steam repository and moves descending, considering the concurrence of minor fluid with vapor in the supply. At the Geysers, a few wells are very nearly 4 km profound and still can't seem to experience the gathered hidden boiling liquid zone from which the steam cap shaped over the long run. Investigation and advancement of these systems have uncovered a moderately uniform temperature of about 250°C and a weight of around 36 kg/cm<sup>2</sup>, or around 34 bars. Therefore, for systems happening at depths greater than 300 m, the steam reservoir pressure is not exactly hydrostatic and turns out to be progressively more so with depth. For this to happen, the steam supply must be essentially disconnected from encompassing water-immersed rock by a pretty much impermeable zone. Otherwise, water would stream into the store under the hydrostatic slope at a rate surpassing the rate of steam release and effectively collapse the under pressured (vapor static or not exactly hydrostatic) steam reservoir. Arrangement of enormous vapor dominated reservoirs in this manner requires an exceptional coordination of topographical cycles, including the essential irregularity between paces of discharge and recharge, pretty much hydrologic reservoir segregation, and an intense hidden heat source for a steam zone to develop over the long run; such imperatives are rarely accomplished topographically.

### III. THERMODYNAMIC ANALYSIS OF THE GEOTHERMAL POWER SYSTEMS

#### A. Analysis of an Underground Thermal Energy Storage System

Energy and work examinations are introduced for underground thermal storage as a spring TES (Thermal Energy Storage) in this part. Information are utilized from the first of four transient aquifers TES test cycles. The capacity and flexibly wells are found 255m separated. The test cycles were performed at the St. Paul grounds of the University of Minnesota in the time period November 1982–December 1983, during which time the normal ambient temperature was accounted for to be 11 °C, and the investigations intently follow past treatments [7]. The tests included three essential working periods, during which the water temperature and volumetric stream rate change transiently:

- 1) *Charging*: Water is siphoned from the source well, warmed in a heat exchanger, and got back to the spring through the storage well. The charging period happened for 5.35 days over a 17-day time span. The charging temperature and volumetric flow rate were roughly consistent at mean estimations of 89.4 °C and 18.6 l/s, separately.
- 2) *Storing*: The capacity period kept going 13 days.
- 3) *Discharging*: After capacity, the energy was recuperated by pumping the stored water through a heat exchanger and returning it to the supply well. Releasing happened over 5.35 days, with an almost consistent volumetric flow rate (with a mean estimation of 18.8 l/s) and a straight diminishing temperature with time (beginning at 74 °C and finishing at 32 °C).

#### B. Energy and work Analyses

To encourage the examinations, we treat the system in the streamlined way portrayed in this subsection. During charging, heated water at a constant temperature  $T_c$  is infused at a constant mass flow rate  $\dot{m}_c$  the aquifer over a period  $t_c$ . After a storing period, releasing happens over a period  $t_d$ , during which water is removed from the aquifer at a constant mass flow rate  $\dot{m}_s$ . The liquid discharge temperature is an infinite time, that is,  $T_d = T_d(t)$ , with the release temperature after an endless time being the temperature of the reference-climate  $T_o$ , that is,  $T_d(\infty) = T_o$ , and the initial discharge temperature being between the charging temperature and the reference-climate temperatures, that is,  $T_o \leq T_d(0) \leq T_c$ . For effortlessness, a release temperature-time profile is considered in which the discharge temperature diminishes straight with time from an underlying worth  $T_s(0)$  to a last an incentive  $T_o$ . The final temperature is reached during a period  $t_f$  and remains fixed at  $T_o$  for all subsequent time:

$$T_d(t) = \begin{cases} T_d(0) - (T_d(0) - T_o)t/t_f, & 0 \leq t \leq t_f \\ T_o, & t_f \leq t \leq \infty \end{cases} \quad (1)$$

All through, pump work is dismissed, and the working liquid, water, is expected incompressible and taken to have a steady explicit heat  $c$ . The temperature of the spring and its environmental factors before heat infusion is the reference-environment temperature  $T_o$  and just heat stockpiling above  $T_o$  is thought of.

### C. Energy and workflows During Charging and Discharging

The energy and work infused during charging and recovered during discharging are assessed. To decide these amounts, we note that the energy flow related to a flow of fluid at a steady mass flow rate  $\dot{m}$  for an arbitrary period of time with  $T$  a function of  $t$ , is:

$$E = \int_t E(t) dt \quad \text{--- (2)}$$

where the integration is performed over the time period, and the energy flow rate at time  $t$  is:

$$E(t) = mc[T(t) - T_o] \quad \text{--- (3)}$$

and  $c$  is as previously defined. Also, the corresponding workflow is:

$$Ex = \int_t Ex(t) dt \quad \text{--- (4)}$$

where the workflow rate at time  $t$  is:

$$Ex(t) = mc\{[T(t) - T_o] - T_o \ln[T(t)/T_o]\} \quad \text{--- (5)}$$

For constant  $\dot{m}$ ,  $c$  and  $T_o$ , we obtain the energy flow by combining Equation (2) and Equation (3):

$$E = \dot{m}c \int_t (T(t) - T_o) dt \quad \text{--- (6)}$$

and the workflow by combining Equation (4) and Equation (5), and substituting Equation (6):

$$Ex = \dot{m}c \int_t [(T(t) - T_o) - T_o \ln(T(t)/T_o)] dt = E - \dot{m}c T_o \int_t \ln(T(t)/T_o) dt \quad \text{--- (7)}$$

During charging, the energy and work input to the aquifer TES, for a constant water injection rate  $\dot{m}_c$  and over a time period beginning at zero and ending at  $t_c$ , are expressed by Equation (6) and Equation (7), respectively, with  $T(t) = T_c$ :

$$E_c = \dot{m}_c c \int_{t=0}^{t_c} (T_c - T_o) dt = \dot{m}_c c t_c (T_c - T_o) \quad \text{--- (8)}$$

$$Ex_c = \dot{m}_c c t_c [(T_c - T_o) - T_o \ln(T_c/T_o)] = E_c - \dot{m}_c c T_o t_c \ln(T_c/T_o) \quad \text{--- (9)}$$

During discharging, the energy recovered from the aquifer TES, for a constant water recovery rate  $\dot{m}_d$  and for a time period starting at zero and ending at  $t_d$ , is expressed by Equation (6) with  $T(t)$  from Equation (1):

$$E_d = \dot{m}_d c \int_{t=0}^{t_d} [T_d(t) - T_o] dt = \dot{m}_d c [T_d(0) - T_o] \theta (2t_f - \theta) / (2t_f) \quad \text{--- (10)}$$

Where,

$$\theta = \begin{cases} t_d, & 0 \leq t_d \leq t_f \\ t_f, & t_f \leq t_d \leq \infty \end{cases} \quad \text{--- (11)}$$

The corresponding work recovery during discharging is expressed by Equation (7), with the same conditions as for  $E_d$ :

$$\begin{aligned} Ex_d &= \dot{m}_d c \int_{t=0}^{t_d} [(T_d(t) - T_o) - T_o \ln(T_d(t)/T_o)] dt \\ &= E_d - \dot{m}_d c T_o \int_{t=0}^{t_d} \ln(T_d(t)/T_o) dt \end{aligned} \quad \text{--- (12)}$$

Here,

$$\int_{t=0}^{t_d} \ln[T_d(t)/T_o] dt = \int_{t=0}^{t_d} \ln(at + b) dt = [(a\theta + b)/a] \ln(a\theta + b) - \theta - (b/a) \ln b \quad \text{--- (13)}$$

Where,

$$a = [T_o - T_d(0)] / (T_o t_f) \quad \text{--- (14)}$$

$$b = T_d(0) / T_o \quad \text{--- (15)}$$

The expression for the integral in Equation (13) reduces when  $t_d \geq t_f$ :

$$\int_{t=0}^{t_d} \ln[T_d(t)/T_o] dt = t_f \left[ \frac{T_d(0)}{T_d(0) - T_o} \ln \frac{T_d(0)}{T_o} - 1 \right] \quad \text{--- (16)}$$

#### D. Energy and Work Balances, Efficiencies and Losses

An aquifer TES energy balance assumed control over a total charging-discharging cycle demonstrates that the input energy is either recovered or lost, while a work balance shows that the input work is either recovered or lost, however, lost work is related to both waste work emissions and internal work utilizations because of irreversibility's. Characterizing  $f$  is as the part of input energy  $E_c$  that can be recovered if the length of the discharge period approaches limitlessness (i.e., water is separated until all recoverable energy has been recovered), we can compose:

$$E_d(t_d \rightarrow \infty) = f E_c \quad \text{---(17)}$$

An energy balance consequently shows that  $(1 - f)E_c$  is the energy irreversibly lost from the aquifer TES and that  $f$  shifts between one for storage without energy losses during a boundless release period to zero for a thermodynamically worthless capacity. work misfortunes can happen regardless of whether  $f = 1$ , in light of the fact that the aquifer TES stays subject to blending misfortunes that diminish the temperature of the recovered water. Since  $E$  is given by Equation (8) what is more,  $E_d(t_d \rightarrow \infty)$  by Equation (10) with  $\theta = t_f$ , Equation (17) can be modified:

$$f = \frac{t_f \dot{m}_d [T_d(0) - T_o]}{2t_c \dot{m}_c (T_c - T_o)} \quad \text{--- (18)}$$

Since  $T_d(0)$  can differ from  $T_o$  to  $T_c$ , the temperature-related term  $[T_d(0) - T_o] / (T_c - T_o)$  shifts among solidarity and zero. Both the time proportion  $t_f / t_c$  and the mass-stream rate ratio  $\dot{m}_d / \dot{m}_c$  can take on sure qualities, subject to the above fairness. The energy (or work) proficiency of the aquifer TES is characterized as the portion over a total pattern of the energy (or work) contribution during charging that is recovered during releasing. As a component of the function time period, the energy productivity  $\eta$  and the work effectiveness  $\psi$  can be communicated, individually, as:

$$\eta(t_d) = \frac{E_d(t_d)}{E_c} = \frac{\dot{m}_d [T_d(0) - T_o]}{\dot{m}_c (T_c - T_o)} \frac{\theta(2t_f - \theta)}{2t_f t_c} \quad \text{--- (19)}$$

$$\psi(t_d) = Ex_d(t_d) / Ex_c \quad \text{--- (20)}$$

The energy efficiency simplifies when the discharge period  $t_d$  exceeds  $t_f$  as follows:

$$\eta(t_d \geq t_f) = f \quad \text{---(21)}$$

Subsequently, for an aquifer TES where all injected energy is recoverable during a discharge release period, that is,  $f = 1$ , the energy effectiveness can arrive at 100% if the discharge period  $t_d$  is adequately long. The comparing work productivity, nonetheless, stays under 100% because of mixing losses, which cause a large part of the heat to be recovered at close natural temperatures [8]. The energy (or work) loss of the spring TES is characterized over a total cycle as the contrast between input and recovered energy (or work). As an element of the release timeframe, in this manner, the energy loss for the aquifer TES system can be communicated by  $E_c - E_d(t_d)$  and the work loss by  $Ex_c - Ex_d(t_d)$ . The two main supporters of the thermodynamic losses are as per the following:

- 1) *Mixing*: As heated water is pump into an aquifer TES, it blends in with the (generally cooler) water present, diminishing the recovered water temperature to lower than that of the infused water. This loss delivers the release temperature  $T_d$  consistently not exactly or equivalent to the charging temperature  $T_c$ , yet not underneath the reference-climate temperature  $T_o$  [i.e.,  $T_o \leq T_d(t) \leq T_c$  for  $0 \leq t \leq \infty$ ]. work losses mirror the temperature degradation related to blending, while energy losses don't.
- 2) *Unrecoverable Heat Transfer*: Energy contribution to an aquifer TES that isn't recovered is lost. Thus, energy loss includes energy staying in the aquifer at a point where it could at present be recovered if siphoning have proceeded, and energy infused into the capacity that is convected in a water stream or is moved by conduction or different systems adequately a long way from the release point that it is unrecoverable, paying little to how much or how long water is siphoned out of the aquifer TES. Non-zero energy misfortunes suggest under 100% of the infused energy is recoverable after capacity. Note that a limit temperature  $T_t$  is normally applied, underneath which it does not merit keeping releasing since the residual energy in the aquifer water is of bad quality. For the direct temperature-time connection here [Equation (1)], the fitting release period can be assessed utilized by using the Equation (1) with  $T_t$  supplanting  $T_d(t)$  for the situation where  $T_o \leq T_t \leq T_d(0)$ .

$$\text{Thus, } t_d = \begin{cases} \frac{T_d(0) - T_t}{T_d(0) - T_o} t_f, & T_o \leq T_t \leq T_d(0) \\ 0, & T_d(0) \leq T_t \end{cases} \quad \text{---(22)}$$

Although heat energy can't be recuperated if the threshold temperature surpasses the underlying discharge temperature, the threshold temperature is in any case significant in light of the fact that, as the discharge time frame expands, water is recuperated from an aquifer TES at consistently diminishing temperatures (at last moving toward the reference-environment temperature), and the energy in the recovered water is of diminishing quality. work examination reflects this impact, as the recovered work diminishes as the recovery temperature decreases.

### E. Assumptions and Results

we are considering that the following water properties will be constant: specific heat (4.2 kJ/kg K) and density (1000 kg/m<sup>3</sup>).

The reference-climate temperature  $T_o$  is taken to be at a constant at the mean ambient temperature of 11° C.

The mass flow rates during charging and discharging are  $\dot{m}_c = 18.6$  kg/s and  $\dot{m}_d = 18.8$  kg/s, respectively, since the volumetric flow rate (in l/s) is equal to the mass flow rate (in kg/s) when the density is 1000 kg/m<sup>3</sup>.

### F. Energy and Workflows During Charging and Discharging Results

During charging, it can be shown using Equation (9.8) and Equation (9.9), with  $t_c = 5.35$  days (453 000 s) and  $T_c = 89.8$  °C (362.8 K),

that

$$E_c = (18.6 \text{ kg/s})(4.2 \text{ kJ/kg K})(453,000 \text{ s})(89.8^\circ \text{C} - 11^\circ \text{C}) = 2740 \text{ GJ and}$$

$$E_{x_c} = 2740 \text{ GJ} - (18.6 \text{ kg/s})(4.2 \text{ kJ/kg K})(453,000 \text{ s})(284 \text{ K}) \ln(362.8 \text{ K}/284 \text{ K}) = 320 \text{ GJ}$$

During discharging, the value of the time  $t_f$  is evaluated using the linear temperature–time relation of the present model and the observations that

$$T_d(t = 5.35 \text{ days}) = 38^\circ \text{C and } T_d(0) = 77^\circ \text{C (350 K)}.$$

Then, using Equation (9.1) with  $t = 5.35$  days,  $38^\circ \text{C} = 77^\circ \text{C} - (77^\circ \text{C} - 11^\circ \text{C})(5.35 \text{ d}/t_f)$

On calculating the equation, we dare to find the final temperature has reached at  $t_f = 8.9$  days, which is the going to discharge period when the discharge water temperature will reach to the  $T_o$ . Note, that the rate of temperature decline which might occur would likely decrease in reality, causing minor diminishing to the discharge temperature to asymptotically approach  $T_o$ . The value of the fraction  $f$ , which is representing the maximum energy efficiency acquirable, can be evaluated with Equation (18) as:

$$f = (8.87 \text{ d})(18.1 \text{ kg/s})(77^\circ \text{C} - 11^\circ \text{C}) / 2(5.35 \text{ d})(18.4 \text{ kg/s})(89.8^\circ \text{C} - 11^\circ \text{C}) = 0.701$$

For these values, it can be shown with Equation (14) and Equation (15) that

$$a = (11^\circ \text{C} - 77^\circ \text{C}) / (284 \text{ K} \times 8.87 \text{ d}) = -0.0262 \text{ d}^{-1}$$

$$b = (350 \text{ K}) / (284 \text{ K}) = 1.232$$

Qualities for charge energy  $E_c$ , charge work  $E_{x_c}$ , release energy  $E_d$ , and release work  $E_{x_d}$  is introduced as a component of discharge time-frame  $t_d$  (Table 5.1). The charged energy and work just appear for a discharge time of zero since the charging period frame is over prior to discharging begins. Note that for times more prominent than the hour of 8.9 days needed to arrive at the last temperature (last column in Table 5.1), the qualities are the equivalent for those during a period of 8.9 days. A standardized adaptation of Table 5.1 is introduced in Table 5.2. There, the time scale is standardized to show the time proportion of  $t_d/t_f$ . Likewise, the charge energy, discharge energy, and energy loss are introduced as a percentage of the charge energy. Essentially, the charge work, discharge work, and work loss are introduced as a percentage of the charge work.

Table 5.1: Temporal Varieties for aquifer heat energy stockpiling, during discharge, of charged, recuperated, and lost energy and work just as energy and work efficiencies.

Quantity	Discharge Time, $t_d$ (Days)					
	0.0	2.2	4.4	6.7	8.9 (= $t_f$ )	>8.9
Energy Quantities						
Charged (GJ)	2740					
Loss (GJ)	2740	1870	1280	920	810	810
Recovered (GJ)	0	810	1400	1750	1860	1860
Efficiency (%)	0	30	51	63	70	70
Work Quantities						
Charged (GJ)	320					
Loss (GJ)	320	240	210	200	180	180
Recovered (GJ)	0	80	110	120	130	130
Efficiency (%)	0	24	35	39	40	40



### G. Energy and Work Efficiencies and Losses Results

The energy loss ( $E_c - E_d$ ) and work loss ( $Ex_c - Ex_d$ ) just as the discharge energy proficiency  $\eta$  and discharge work efficiency  $\psi$  are given as an element of discharge time span  $t_d$  in Table 5.1. As  $t_d$  rises, the energy and work efficiencies in Table 5.1 both increment from zero to most extreme qualities, and the contrast between the two efficiencies increments. Consequently, the work effectiveness loads the energy recovered at higher  $t_d$  values not exactly the energy efficiency, since that energy is recovered at a temperature closer to that of the reference environment. Note in Table 5.1 that as  $t_d$  approaches  $t_f$  (1) all boundaries level off for the conditions determined and stay steady for  $t_d \geq t_f$ , while (2) the energy recovered increments from zero to a maximum value and the energy loss diminishes from a maximum of all the input energy to a minimum (yet non-zero) value. The work recovered and work loss functions show a lot of lower sizes however comparable profiles.

Table 5.2: Standardized transient varieties for aquifer heat energy stockpiling, during discharging, of charged, recovered, and lost energy and work.

Quantity	Ratio of Discharge time to time final temperature is reached, $t_d / t_f$					
	0.0	0.25	0.5	0.75	1.00	>1.00
Energy Quantities						
Charged Percentage	100					
Loss Percentage	100	70	49	37	30	30
Recovered Percentage (or Efficiency)	0	30	51	63	70	70
Work Quantities						
Charged Percentage	100					
Loss Percentage	100	76	65	61	60	60
Recovered Percentage (or Efficiency)	0	24	35	39	40	40

In the standardized rendition of Table 5.1 appeared in Table 5.2, the energy loss and work loss communicated as a level of the charged energy and work, separately, are given as a function of the proportion of release time to time final temperature is reached,  $t_d/t_f$ . The discharge energy productivity and discharge work effectiveness are likewise appeared against this time proportion in Table 5.2. Note that the recovered energy and work rates relate to the energy and work efficiencies, separately [9]. The deviation among energy and work efficiencies is owing to temperature contrasts between the charging and discharged liquids. As the releasing time builds, the deviation increments on the grounds that the temperature of recovered heat diminishes (Table 5.1 and Table 5.2). The energy effectiveness arrives at around 70% and the work productivity 40% toward the fruition of discharging, despite the fact that the efficiencies are both 0% when discharging starts. Note that if a limit temperature is presented (set to the genuine temperature toward the finish of the release time of 5.35 days, i.e., 38 °C), the information in Table 5.1 and Table 5.2 for  $t_d = 5.35$  days apply. At that point, the discharged work (127 GJ) is 91% of the work recoverable in boundless time (139 GJ), however, the discharge energy (1600 GJ) is just 83% of the maximum recoverable energy (1920 GJ). Besides, the work proficiency 40% is close to the work effectiveness feasible in boundless time (43.5%), in spite of the fact that the energy efficiency (58%) remains incredibly underneath definitive energy effectiveness achievable (70%). Correspondingly, the work loss (190 GJ) surpasses the work loss in boundless time (180 GJ) by 5.5%, while the energy loss (1140 GJ) surpasses the energy loss in boundless time (820 GJ) by 39%. The outcomes recommend that aquifer TES performance measures dependent on work are more valuable and significant than those dependent on energy, generally on the grounds that work efficiencies represent the temperatures related with energy moves to and from the aquifer, just as the amounts of energy moved, while energy efficiencies account just for last mentioned. Energy efficiencies can be misleadingly high, particularly when the heat is recovered at temperatures too low to possibly be valuable.

### H. Analysis of a Ground-Source Heat Pump System

Energy and work examinations of a hybrid GSHP system, which utilizes a cooling tower for heat dismissal, are introduced in this part. The system considered is calculated in nature, and the material introduced here draws broadly on prior reports.




Figure 5.1 Hybrid Ground – Source Heat Pump System

### 1) System Description and Operation

The hybrid GSHP framework considered is appeared in Figure 5.1 It has three primary loops:

- A typical inside building heat pump circle gives heating to the structure and its ecological zones. That circle contains a water-source heat pump. The inside building heat pump loop fills in as a heat source or ink, contingent upon the heating or cooling requests. The working liquid in the heat pump is R-134a.
- The inside building heat pump loop is associated with a ground heat exchanger circle. The ground gives a heat source and a heat sink for the general system.
- A cooling tower is associated in arrangement with the ground heat exchanger in the hybrid framework, in a cooling tower loop. The cooling tower fills in as a supplemental heat dismissal gadget and is utilized to guarantee the energy streams to and starting from the earliest stage in equilibrium throughout the year. The cooling tower circle is segregated from the structure and ground channelling loops with a plate heat exchanger.

Table 5.3: Work and heat rates for the components in the Crossbreed Ground-Source Heat Pump System.

Device	Heat Transfer (kW)	Work Input Rate (kW)
Compressor	-	0.70
Condenser	4.1	-
Expansion Valve	-	-
Evaporator	3.4	-
Plate Heat Exchanger	13.5	-
Pump	-	0.06

Note that devoted water-to-water heat pumps may likewise be associated with the regular inside building heat pump loop to meet domestic water heating requirements for the structure. The mechanical work and warmth move rates related to the segments are given in Table 5.3. The framework is taken to work in the accompanying encompassing conditions: a temperature of 2.3 °C and a weight of 112.325 kPa.

- Analyses:* Energy and work examinations of the hybrid GSHP framework are performed following the methodology. Mass, energy, and work balances are applied to the framework and its fundamental parts to decide energy and work efficiencies, just as the paces of work loss and work destruction [10]. The crossbreed GSHP framework is evaluated while working at a consistent state. Dynamic and expected energies and work terms are dismissed as is chemical work since it isn't applicable to the examinations. The reference climate for work investigation is taken to be at the surrounding conditions determined previously. The coefficient of performance (COP) for the general framework is assessed as the proportion of the heat transfer rate in the condenser Figure 5.1 to the complete energy input rate to the system as work:

$$COP_{sys} = \frac{Q_{cond}}{W_{comp} + W_{pump}} \quad \text{--- (23)}$$

The COP gives an energy-based proportion of performance.

A relating work proficiency for the general framework can be composed as the proportion of the heat work transfer rate in the condenser to the all-out work input rate to the system:

$$\psi_{sys} = \frac{Ex_{out}}{Ex_{in}} = \frac{Ex_2 - Ex_3}{W_{comp} + W_{pump}} \quad \text{--- (24)}$$

- Analyses of Primary Mechanical Devices:* The essential mechanical devices in the framework are the compressor, the pump, and the expansion valve. The compressor and the pump somewhat similar to each other and in this way can be surveyed in a typical way. That is, the work productivity of these two devices can be assessed as the proportion of the pace of work increment of the stream being expanded in pressure to the pace of work contribution as work to the device. The work efficiency would thus be able to be composed for the compressor as:

$$\psi_{comp} = \frac{\dot{Ex}_2 - \dot{Ex}_1}{W_{comp}} \quad \text{--- (25)}$$

Also, for the pumps as

$$\psi_{pump} = \frac{\dot{Ex}_{12} - \dot{Ex}_{11}}{W_{pump}} \quad \text{--- (26)}$$

An expansion valve is a device where the pressure of the refrigerant is diminished with no item yield (like mechanical power). An expansion valve is a dissipative gadget with no logical product. Subsequently, it is preposterous to expect to assess ordinary effectiveness for it. In any case, fairly significant work effectiveness can all things considered be composed for the expansion valve as the proportion of its work yield rate to work input rate:

$$\psi_{\text{valve}} = \frac{\dot{E}x_4}{\dot{E}x_3} \text{ ---(27)}$$

The contrast between the numerator and denominator here speaks to the work obliteration rate in the expansion valve. Note that the work proficiency of the expansion valve can on the other hand be communicated as follows:

$$\psi_{\text{valve}} = \frac{\dot{E}x_{\text{out}}}{\dot{E}x_{\text{in}}} = 1 - \frac{\dot{E}x_{\text{dest}}}{\dot{E}x_{\text{in}}} = 1 - \frac{\dot{E}x_3 - \dot{E}x_4}{\dot{E}x_3} \text{ ---(28)}$$

With this definition, the work proficiency of the expansion valve is zero, which can be seen as more important since the entirety of the used work is lost, reflecting the profoundly irreversible nature of the device.

- 4) *Examinations of Primary Heat Exchange Devices:* The essential heat exchange device in the system are the heat exchanger, the condenser, and the evaporator. Like a portion of the mechanical device, they carry on also and hence can be surveyed in a typical way. The entirety of the heat exchanger device has an information cold stream which is heated by a different input hot stream [11]. The work efficiency of each heat exchange device is assessed as the proportion of the pace of work increment of the cold stream to the pace of work reduction of the hot stream. With this methodology, the work proficiency can be composed for the condenser as:

$$\psi_{\text{cond}} = \frac{\dot{E}x_5 - \dot{E}x_6}{\dot{E}x_2 - \dot{E}x_3} \text{ ---(29)}$$

for the evaporator as:

$$\psi_{\text{evap}} = \frac{\dot{E}x_9 - \dot{E}x_7}{\dot{E}x_4 - \dot{E}x_1} \text{ ---(30)}$$

also, for the plate heat exchanger is:

$$\psi_{\text{PHX}} = \frac{\dot{E}x_7 - \dot{E}x_8}{\dot{E}x_{12} - \dot{E}x_{10}} \text{ ---(31)}$$

- 5) *Work Destruction Rates:* Work Destruction rates for the hybrid GSHP are recorded in Table 5.4. The best work obliteration rates happen in the compressor and the condenser. The work obliteration rates in these parts are brought about by contact and heat transfer over a limited and generally enormous temperature distinction. The work efficiency of the expansion valve assessed dependent on Equation (27) is high (94.6%), reflecting the way that a large portion of the work entering the expansion valve exits.

Table 5.4. Exergy destruction rates and efficiencies for the general hybrid ground-source heat pump framework and its gadgets.

Device	Work Destruction rate		Work Efficiency (%)
	Absolute (kW)	Relative (% of Total)	
Compressor	0.17	33	75
Condenser	0.13	24	79
Expansion Valve	0.03	6	94
Evaporator	0.13	24	8
Plate Heat Exchanger	0.05	9	88
Pump	0.02	3	71
Overall System	0.53	100	63

- 6) *Efficiencies:* Work efficiencies for the hybrid GSHP are recorded in Table 5.4. The COP of the system is discovered to be 5.34 and the work efficiency 63.4%. These qualities are high however not absurd. It is informative to think about the COP and work efficiency for the current system with relating values for other similar systems. In one separate evaluation, the GSHP system has been appeared to have a work efficiency of 68.1% and a COP of 2.27–3.14. In another appraisal, a GSHP system was appeared to have a COP of 3.64. The higher COP for the last case is chiefly connected with the generally higher temperature of geothermal water regarding the ground. Similar information recommends that mixture GSHPs can accomplish higher COPs than ground-and air-source heat pumps, as the COP values revealed such systems don't surpass four. Consolidating another source of heat energy (e.g., solar-powered energy or geothermal water) into a system may consider higher COPs. The aftereffects of the energy and work efficiencies of a hybrid GSHP systems recommend that hybrid GSHP systems work at higher COP and work efficiencies than ordinary air-source heat pump systems. The last normally display COPs of 1–3 and work efficiencies under 30%.


#### IV. CHEMISTRY OF GEOTHERMAL FLUIDS

##### A. Why the Geochemistry of Geothermal Fluids Matters?

Water happens basically wherever in the subsurface. For applications that require temperatures of two or three many degrees centigrade or less, for example, heat for direct-use applications or for heating-ventilation-air conditioning (HVAC) purposes, fleeting waters that happen in shallow groundwater systems are typically adequate to give the required energy. heat pumps can effectively move heat in such systems. Since such frameworks lead to a generally little temperature drop in the liquids, and in light of the fact that the science of the liquid is of minimal direct ramification for these utilizations, it isn't important to seek after pointing by point information on the liquid science for such applications. That isn't the situation for cases wherein higher temperature liquids are required. The high-temperature liquids utilized in geothermal power creation are regularly connected with magma bodies or are in districts where molten action has happened in the ongoing past. In those situations where the ongoing molten movement isn't important for the geological history, geothermal liquids can form where deep fluid circulation, often facilitated by fracturing and breaking, permits water to arrive at depths where adequate heat is accessible to raise the temperature above 160°C. In one or the other case, the water will interface with the surrounding rocks, taking on compound qualities that are affected by the nearby geography. These connections confer a compound mark to the water [12]. Decoding the ramifications of that signature for the nature of the asset and the potential economic and ecological effects that may be tended to, relies on a definite comprehension of the watery geochemistry. The geochemistry of common waters is likewise significant for an alternate, however similarly as essential, part of geothermal energy contemplations; specifically, investigation for the asset. In numerous occurrences, surface proof that a high-temperature asset is available at depth may not be self-evident, subsequently making the resource hard to track down. These "covered up" resources are frequently perceptible through substance marks in surface waters. A portion of these marks can be explicit synthetic constituents that demonstrate the presence of a warmth irregularity at depth, in different cases, it very well might be moved in the conveyance examples of specific components, isotopes or mixes, or changes in the proportions of components. Understanding the cycles that control these geochemical marks gives the capacity to evaluate the worth and nature of a resource.

##### B. Components and Chemical Systems

Any assortment of compounds, regardless of whether they be metals, singular components, blended gases, blended fluids, consolidated solids, or any mix of these, are made from substance constituents. The base number of these compound constituents that are expected to completely portray the assortment of substances are characterized as the parts of the system. How these segments are distinguished relies on how the system is to be broken down. In building up our rundown of segments it is significant that they portray the system totally and are not themselves made from at least two substances that happen in our system. The substances that make up the systems are the stages, which can be minerals, gases, or fluids. For instance, think about the mineral's quartz, cristobalite, and chalcedony, all of which have the compound equation  $\text{SiO}_2$ . These three stages are the systems we will consider. The distinction between them is how the molecules in the mineral structures are arranged. Three chemical reactions can be composed that totally portray the potential connections of the minerals.




There are two manners by which the segments of this system can be characterized. One path is to take note of that the components Si and Oxygen make all out of the minerals in this system and can along these lines totally depict the compound properties. It is likewise conceivable, in any case, to utilize  $\text{SiO}_2$  as a substance part since it, as well, gives a total depiction of this system. Indeed, it is the best and fundamental approach to depict this system since it permits the most modest number of components to be utilized for characterizing the system. Assuming, nonetheless, we were keen on the separation of these minerals into their nuclear constituents, at that point we would need to utilize Si and O as the segments, as opposed to  $\text{SiO}_2$ .

##### C. Chemical Potentials, $\mu$ , and Gibbs Energy

When the parts are distinguished for a system it is conceivable to portray such things as what mineral or assortments of minerals will be the steady phases in the systems under a given arrangement of pressure and temperature conditions. Every part in a mineral has a compound potential,  $\mu$ , which has units of J/mole. Substance possibilities are comparable to gravitational possibilities or electrical possibilities. They are a proportion of the inclination of a synthetic segment to change starting with one energy state then onto the next.



Consequently, in our model, we are thinking about the tendency of the part  $\text{SiO}_2$  to exist in either the quartz, cristobalite, or chalcedony arrangement. The steady setup of a system is what gives the least energy state. Henceforth, in our model, the basis for recognizing the steady phase is to decide for which mineral stage the compound capability of  $\text{SiO}_2$  is the least. Obviously, this will rely upon the pressure and temperature conditions to which the system is subject. The change starting with one stage then onto the next, for example,



is a chemical reaction that will happen at some arrangement of states of being? In the event that all such states of being are considered, the response will characterize a limit, on one side of which quartz, the reactant, will be steady and on the opposite side tridymite, the reactant, will be steady (by the show, reactants are those stages that happen on the left half of the reaction and products happen on the correct side of the response). Along with that limit, the chemical potential of  $\text{SiO}_2$  in the two stages is equivalent

$$\mu_{\text{quartz}} = \mu_{\text{tridymite}}.$$

The different responses that are conceivable in the example systems are effectively spoken to as articulations between parts since there is just a single segment in the system, and that segment is the just one present in the stages we are thinking about. Be that as it may, in more intricate frameworks, for example, those typically experienced in geothermal frameworks, monitoring how the entirety of the parts are independently changing as the states of being advance is just excessively awkward. All things being equal, the accompanying relationship is utilized to represent these changes:

$$\Delta G_j = \sum \mu_j^i \text{ ---(1)}$$

Where  $\Delta G_j$  is the Gibbs energy of stage  $j$  and  $\mu_j^i$  the chemical potential of component  $i$  in phase  $j$ . In the summation, it is shown that the products are taken as positive linear and the reactants are taken as negative linear.

Reviewing the meaning of the Gibbs work, it is obvious that the amount of the chemical potentials of the segments of a phase communicates the adjustments in enthalpy, entropy, and PV work that happen when a stage is influenced by developing states of being. Condition (1) is a significant general articulation for all phases. It demonstrates that all stages that make up an actual framework will react to changes in their current circumstance through the impacts those progressions have on the substance possibilities of the segments creating the phase. Those progressions will be communicated in an assortment of ways. In any case, the most dramatic change is that suggested by the chemical reactions we are thinking about. Adequate change in the chemical potential of the segments creating a phase will eventually be adequate to make that stage unsteady, comparative with some different plans of the components, and a reaction will happen, framing another assemblage of phases. This at that point infers that Equation (1) can be summed up to speak to the conduct of an assortment of phases,

$$\Delta G_{rx} = \sum \Delta G_j, \text{ ---(2)}$$

where  $\Delta G_{rx}$  is the Gibbs energy of the reaction we are thinking about, at some predefined pressure and temperature. Once more, a similar show with respect to the indication of the reactants and items is utilized in the summation as in Equation (1).

#### D. Kinetics of Geothermal Reactions

How rapidly materials break up in or precipitate from a solution, and along these lines how rapidly the equilibrium will be drawn closer, is controlled by the temperature and pressure, the compelling surface zone presented to the solution, the chemical composition of the solution, and how promptly mineral parts can be eliminated from or added to the uncovered surface of solids with which the liquid is in contact. The rate at which such a cycle continues is known as the kinetics of the energy and is portrayed by a condition that is the applicable reaction rate law. In its most broad structure, a reaction rate law will be a portrayal of the variables affecting dissolution or precipitation rate:

$$R = SA \times k \times T_{\text{fac}} \times \alpha \times \phi \times \Pi a_i \times (1 - Q/K)\omega, \text{ ---(3)}$$

where  $R$  is the rate (moles/s),  $SA$  is the viable surface area presented to the liquid ( $\text{cm}^2$ ),  $k$  is the far from equilibrium rate constant (moles/ $\text{cm}^2$ -s),  $T_{\text{fac}}$  is the temperature correction factor for the rate consistent  $k$  (generally an Arrhenius work),  $\alpha$  is a power function that represents changes in the rate near balance conditions,  $\phi$  is a capacity that adjusts the rate for precipitation comparative with that for dissolution that depends on exploratory information,  $a_i$  represents the dependence of the rate on the activities of specific components in solution (regularly this is chiefly an impression of the movement of the hydrogen particle,  $\text{H}^+$ ),  $Q/K$  is the activity quotient for the relevant species in the applicable reaction by equilibrium constant for that same reaction, and  $\omega$  is power reliance dependent on test information that represents the specific dissolution or precipitation component. Given the quantity of moles present, the time needed to break down material, or the time needed to encourage a given measure of material can be determined from Equation (3).





Figure 6.1 The time needed for a reaction to go to culmination, as a function of the uncovered surface area. The  $\Delta T$  values show the temperature over-stepping, comparative with the equilibrium temperature for the thought about reaction, for this situation, the dehydration reaction for muscovite. Additionally, indicated is the range of times the quartz to encourage from hydrothermal liquids in the temperature scope of about  $100^{\circ}\text{C}$ – $300^{\circ}\text{C}$ . The arrows show the all-out surface region, per kg of rock, of a spherical mineral with a span of 0.1 centimetres if the mineral forms 5 vol.% and 10 vol.% of the stone.

Infrequently, in any case, are there adequate information accessible to apply Equation (3) in a thorough manner to common systems and cycles. High accuracy and all-around decided rate constants, for instance, are known for several minerals, and these can vary by numerous significant degrees. Moreover, the conditions on  $\alpha$ ,  $\phi$ ,  $\Pi$ , and  $\omega$  are infrequently known. Therefore, different simplifications to rate laws have been proposed to represent the conduct of specific minerals or set-ups of minerals for a restricted scope of mineral-liquid conditions or streamlining presumptions are made to permit approximations to be processed for the degree to which response progress happens [13]. By the by, significant knowledge can be picked up by thinking about how paces of responses impact what can be seen in characteristic frameworks, in any event, utilizing the restricted data accessible to us. To act as an illustration of the understanding that can be picked up by assessing response progress, consider the subject of how response time is influenced by grain size and temperature. Accept that we are thinking about a system in which a mineral has a realized disintegration rate consistent that was tentatively estimated for a given arrangement of conditions. We additionally know how that rate constant changes as temperature ascends past the conditions for which  $Q/K$  equivalents 1.0. Plotted in Figure 6.1 are the necessary occasions for such a response to go to fulfilment, as an element of the uncovered surface zone and the degree to which the temperature of the system surpasses the equilibrium temperature for the reaction.

The Figure 6.1 shows a few key issues relevant to understanding the geochemistry of geothermal systems. Premier is that the geochemistry of a specific geothermal systems is not probably going to be an impression of a balanced state. The time it takes to accomplish equilibrium for a particular response can change from seconds to a huge number of years, depending on the conditions at a particular area. The dissolution rates, at  $24^{\circ}\text{C}$ , for quartz and halite, for instance, are  $1.26 \text{ e}^{-14} \text{ moles/cm}^2 \cdot \text{s}$  and  $1.0 \text{ e}^{-5} \text{ moles/cm}^2 \cdot \text{s}$ , separately. Given the amazingly heterogeneous circulation, on the meter scale, of mineralogy, grain size, pore-volume, porousness, uncovered surface zone, liquid structure, etc, many contending responses will happen at the same time, each moving toward a balanced condition at an alternate rate. Subsequently, while thinking about the qualities of a geothermal site, it is wise to see those conditions as basically a point along a transformative pathway. The figure additionally represents the overall affectability of reaction progress to bothers in temperature and changes in the surface zone along a stream way. Note few tens of degrees contrast in the temperature, comparative with the equilibrium temperature of reaction, can change the time it takes to accomplish total response by many years. Changes in the uncovered surface regions will likewise influence the time needed to accomplish total response, however, the impact is less articulated than for temperature, mirroring the way that responses scale around straight with the surface region, yet dramatically with temperature, as is apparent from Equation (3). In spite of the fact that the outcomes in Figure 6.1 are explicit to the strategy, different methodologies and different reactions would give subjectively comparative outcomes, as in bigger surface regions and higher temperatures (comparative with the equilibrium temperature) bring about more limited reaction times. Nonetheless, the supreme changes in response times will rely upon the measure of the minerals present, it's surface region, and the reaction rate for the collection of minerals associated with the response at the temperature of the systems. Obviously, to get an exact comprehension of a particular geothermal systems requires information on the mineralogical attributes all through the flow regime the geothermal systems has influenced.

### E. Gases of Geothermal Fluids


Geothermal fluids consistently contain a dissolved gas segment that can assume a significant part in setting up the chemical attributes of the liquid. The source and impact of that component are multifaceted. As recently referenced, the heat source for geothermal systems is the fundamental magmatic system, which has perturbed the nearby geography. At the point when magmas are produced, generally numerous kilometres underground, they incorporate parts of the stones that softened to shape them. Since the melting cycle includes huge volumes of various minerals, the melts that are created are complex chemical systems that contain practically every component in the periodic table. As the melts relocate to shallow levels in the covering, cool, and begin to take shape, a fractionation cycle happens in which a few components are specially joined into the recently framing minerals, and others are prohibited in light of the fact that they don't find a way into the precious stone structure of the new minerals. A large number of the avoided components and mixes tend to shape unstable mixes, including  $\text{H}_2\text{O}$ ,  $\text{CO}_2$ ,  $\text{H}_2\text{S}$ ,  $\text{O}_2$ ,  $\text{CH}_4$ , and  $\text{Cl}_2$ . As the magma solidifies, the decreasing volume of liquid material that contains these mixes as a dissolved load, in the long run, arrives at immersion in them and they start to exsolve, moving from the taking shape magma into the encompassing stone. As these volatiles relocate upward, they communicate with geothermal liquids and groundwater. Therefore, geothermal liquids can contain raised convergences of these constituents. The host rocks through which warmed geothermal liquids relocate likewise can add to the advancement of a broke down gas part. In the event that, for instance, the stones contain calcite ( $\text{CaCO}_3$ ), dissolution of that mineral will build the measure of carbonate ( $\text{CO}_3 =$ ) and bicarbonate ( $\text{HCO}_3 -$ ), which eventually will expand the broke down  $\text{CO}_2$  content through the responses recorded underneath. The impact of these components is communicated in the fluid chemistry that happens in the solution. A portion of the reactions in which these mixes are included, and their individual log K qualities at  $26.5^\circ\text{C}$ , are the accompanying:



Notice that every one of these responses include  $\text{H}^+$ , which emphatically impacts the acidity of a solution. The solid connection amongst acidity and chloride concentration mirrors the way that the expansion of chloride to an answer will make hydrochloric acid ( $\text{HCl}$ ), and  $\text{HCl}$  firmly favours high activities of hydrogen ion in solution, as inferred by the enormous positive log K value appeared above in equation.

### F. Gas Partitioning among Liquid and Vapor

In geothermal systems utilized for power creation, the dissolved gases can importantly affect the designing and the executives of the power generation complex. dissolved gases will remain in solution except if the pressure is diminished, which is what occurs as geothermal liquids are brought to the surface and used to turn turbines. For this situation, nonetheless, expect that the arrangement is one of the liquids recorded, in which there are dissolved gases. At the point when the liquid arrives at point A, steam starts to isolate. Since dissolved gases have distinctive thermodynamic properties (which is archived by the varying log K qualities over), some will have started to exsolve from the solution prior to that point, while others will in any case be in solution. When steam structures, notwithstanding, another cycle starts to impact the conduct of the dissolved gases; specifically, the need to partition the all-out mass of each dissolved species among fluid and gas (steam). Thermodynamically, this dividing cycle reflects the driving force for all substances to accomplish a thermodynamic balance condition, which can be communicated as (utilizing  $\text{H}_2\text{S}$  as an example species):



where  $\mu_{\text{H}_2\text{S}}(\text{aq})$  and  $\mu_{\text{H}_2\text{S}}(\text{g})$  represent the chemical potential of the Hydrogen Sulfide dissolved in the watery solution and in the gas phase, separately. As recently noticed, the chemical potential is the amount of the relative multitude of properties of the systems that decide the thermodynamic energy of a substance (e.g., enthalpy, entropy, PV work, and so forth) and is a definitive main impetus for any chemical reaction. At harmony, all the chemical potential of taking an interest substance in all stages must be equivalent, by definition. All mixes must comply with this guideline. For our contemplations, the inquiry we should deliver is the means by which to decide the amount of the compound must enter the gas phase with the end goal for equilibrium to be accomplished. Presently, dependence is set on experimental data to build up the apportioning relationship for any species, since the theoretical, quantum mechanical computations are very overwhelming.

$$\ln KD = (-0.023767 \times F) + \{E/T \times [(p_l/p_{cp}) - 1]\} + (F + \{G \times [1 - (T/T_{cp})^{2/3}] + \{H \times [1 - (T/T_{cp})]\} \exp \{[273.15 - T]/100\}),$$




Figure 6.2 The variety of the log of the steam: fluid circulation coefficient (KD) of selected gases with temperature.

where KD is the mass proportion between the gas and fluid periods of the species of interest, T is in degrees Kelvin,  $T_{cp}$  is the temperature at the critical point of water (646.024 K),  $p_l$  is the thickness of water at the temperature of interest,  $p_{cp}$  is the thickness at the critical point of water, and E, F, G, and H are correlation parameters. Figure 6.2 shows the variety of log KD with temperature for  $H_2$ ,  $O_2$ ,  $CO_2$ , and  $H_2S$ .

The figure exhibits the strong partitioning into the gas phase of these species and the solid temperature reliance of the partitioning. Notice that, at high temperatures, the dividing for these gases is inside a significant degree of one another. As the gases cool, the distinctions in thermodynamic properties bring about broadly different partitioning behaviour with the end goal that, at 100°C, the distinction in partitioning is more than over two significant degrees. In addition to other things, this implies that gas analyses did at a low temperature must be adjusted for this difference in partitioning behaviour if remaking of the water composition inside a geothermal spring is to be acquired.

## V. CONCLUSION

Utilizing sustainable energy is a significant viewpoint in these everyday lives we have to adapt up to environmentally friendly power sources at the earliest opportunity to ensure we probably won't increase the temperature of the earth. Geothermal energy is protected and conspicuous energy areas in environmentally friendly power sources.

This exploration managed different physical and chemical properties that may have any kind of effect on the geothermal plants and make changes in their proficiency, it additionally made contrasts and varieties in the two most utilized geothermal plants like underground geothermal system and hybrid geothermal heat pump framework. The efficiencies these systems produce matters the most make these plants more reachable and can run effectively for additional years. The orderly methodology these plants need is vital tests in the effectiveness rates, the work loss, the work gains, discharging and discharging season of the fluids utilized in the system have a basic effect to the final product in these plants.

The liquids used in these geothermal plants have a significant effect this is a result of their characteristic natural habitat and parameters influencing them to have its effect on the end productivity rate at which the electricity is produced by these plants. Various chemicals vary in their chemical potential when they are joined with other comparative builds causing differences to make and might result in different efficiencies.

We expected not many blends so which course observe rate may increase which may be speculative yet can be accomplished at a more prominent rate each and every idea had here may affect climate in various or in an ordinary manner however it the same time the effect isn't high has non-renewable fuel source that is the thing that makes geothermal energy one of the sleekest and sharpest energy in the environmentally friendly power energy area.



## REFERENCES

- [1] Manzella, A., Allansdottir, A. and Pellizzone, A. eds., 2019. Geothermal energy and society. Springer.
- [2] Barbier, E., 2002. Geothermal energy technology and current status: an overview. Renewable and sustainable energy reviews, 6(1-2), pp.3-65.
- [3] Pang, Z.H. and Reed, M., 1998. Theoretical chemical thermometry on geothermal waters: problems and methods. Geochimica et Cosmochimica Acta, 62(6), pp.1083-1091.
- [4] Arnórsson, S., 2000. Isotopic and chemical techniques in geothermal exploration, development and use. International Atomic Energy Agency, pp.109-111.
- [5] Energy, G., 1997. Power From the Depths,". Energy Efficiency and Renewable Energy, pp.1-7.
- [6] Oldenburg, C.M. and Pruess, K., 1998. Layered thermohaline convection in hypersaline geothermal systems. Transport in Porous Media, 33(1-2), pp.29-63.
- [7] Reistad, G.M., Yao, B. and Gunderson, M., 1978. A thermodynamic study of heating with geothermal energy.
- [8] Dumitraşcu, G., Dumencu, A., Horbaniuc, B. and Atanasiu, M.V., 2016. Thermodynamic analysis of geothermal heat pump during the cold season. MS&E, 147(1), p.012137.
- [9] Yildirim, D. and Ozgener, L., 2012. Thermodynamics and exergoeconomic analysis of geothermal power plants. Renewable and Sustainable Energy Reviews, 16(8), pp.6438-6454.
- [10] Lubis, L.I., Kanoglu, M., Dincer, I. and Rosen, M.A., 2011. Thermodynamic analysis of a hybrid geothermal heat pump system. Geothermics, 40(3), pp.233-238.
- [11] Pasek, A.D., Soelaiman, T.F. and Gunawan, C., 2011. Thermodynamics study of flash–binary cycle in geothermal power plant. Renewable and Sustainable Energy Reviews, 15(9), pp.5218-5223.
- [12] Arnórsson, S., Gunnlaugsson, E. and Svavarsson, H., 1983. The chemistry of geothermal waters in Iceland. III. Chemical geothermometry in geothermal investigations. Geochimica et Cosmochimica Acta, 47(3), pp.567-577.
- [13] Rogers, P.S.Z., 1981. Thermodynamics of geothermal fluids.



10.22214/IJRASET



45.98



IMPACT FACTOR:  
7.129



IMPACT FACTOR:  
7.429



# INTERNATIONAL JOURNAL FOR RESEARCH

IN APPLIED SCIENCE & ENGINEERING TECHNOLOGY

Call : 08813907089  (24\*7 Support on Whatsapp)